

Transport and installation instructions

as from serial No. 5012001

TNA400 TX8i-s

Note on applicability

Illustrations in this publication may deviate from the product supplied. Errors and omissions due to technical progress expected.

A word on copyright

This document is protected by copyright and was originally compiled in German.

The duplication and distribution of this document or parts thereof is prohibited without prior consent of the copyright owner, and any violators will be prosecuted. All rights, including the right to translate, are reserved.

© Copyright by INDEX-Werke GmbH & Co. KG

Safety	5
Symbols	5
Documentation safety instructions	5
Installation and layout diagrams	7
Installation diagram	7
Foundation diagram	8
Layout diagram	9
Installation diagram with DNH 61/81 - 3000	10
Installation diagram with DNH 61/81 - 4000	11
Installation diagram TNA 400-65 QUICK LOAD SERVO 3, loading from the front	12
Installation diagram TNA 400-65 QUICK LOAD SERVO 3, loading from the rear	13
Installation diagram TNA 400-80 QUICK LOAD SERVO 3, loading from the front	14
Installation diagram TNA 400-80 QUICK LOAD SERVO 3, loading from the rear	15
General data	17
Ambient conditions	18
Concrete flooring and/or intermediate floors	18
Ground floor	18
Foundation data	18
Machine weight and dimensions	19
Preparing the machine for transport	21
Position of the turret-type tool head	21
Close open hose or pipe lines	21
Attach transport retainer	21
Corrosion protection	21
Transporting the machine	23
Packaging of the machine, machine components and accessories	23
Centre of gravity of the machine (S) TNA 400 TX8i-s	24
Loading and shipping in crate	25
Machine ready for shipment	25
Transporting the machine with a fork lift truck	26
Fork lift truck requirements	26
Transporting the machine by crane (min. load capacity 6 t)	27
Set of hoisting gear and fittings	27
Suspension points, front view	28
Transporting the machine by truck	29
Securing the load	30

Installation of the machine	33
Remove transport retainer	33
Aligning and anchoring the machine	34
Transport and installation of the chip conveyor	35
Transport and installation of the lubricoolant unit	36
Indicator lamp	36
Fuels	36
Switching on the machine	36
 Electrical connection	 37
Notes	37
 Fuels	 39
Overview of fuels	39

Symbols

This chapter describes the symbols used in the documentation for users to highlight risks and tips.



This symbol draws attention to imminent danger to life and health. Failure to observe this danger sign can result in serious damage to health, as well as potentially fatal injuries and even death.



This symbol draws attention to imminent danger due to electricity. Failure to observe this danger sign can result in serious damage to health, as well as potentially fatal injuries and even death.



This symbol draws attention to important information on correct operation of the machine. The machine or parts of the machine may be damaged or malfunction if these instructions are not observed.


Documentation safety instructions



The documentation for users and particularly the safety instructions must be observed.
The safety instructions are set out in a separate document forming part of the TRAUB documentation for users.


Installation diagram

Drawing No. 949890, sheet 1



Foundation diagram


Drawing No. 949890, sheet 2




Layout diagram

Drawing No. 949890, sheet 3

Scale 1:100




Scale 1:50



- = Operator side
- = Electrical connection
- = Hydraulic unit

Installation diagram with DNH 61/81 - 4000


Drawing No. 943323



Installation diagram TNA 400-65 QUICK LOAD SERVO 3, loading from the front

Max. material bar length 1000 mm


Drawing No. 948460




Installation diagram TNA 400-65 QUICK LOAD SERVO 3, loading from the rear

Max. material bar length 1000 mm

Drawing No. 948461




Drawing No. 948476



Installation diagram TNA 400-80 QUICK LOAD SERVO 3, loading from the rear

Max. material bar length 1000 mm

Drawing No. 948475





Beware of being crushed

The installation site must be selected in such a way that there is no risk of anyone or anything being crushed against walls, pillars or hall installations by moving parts or the machine, including manually operated doors and flaps, etc.



Danger due to falling machine / parts

Ensure there is no-one underneath the suspended load!



Transporting the machine

The machine can be transported with the aid of a crane or fork lift truck.



The machine with bar loading magazine must in all cases be anchored in the ground.

The machine can be transported at temperatures down to -20 °C.
Special precautions must be taken when transporting the machine in regions with temperatures below -20 °C.

Ambient conditions

Min. room temperature	5°C
Max. room temperature	40°C
Max. humidity	50%
Transport temperature	max. - 20°C

Concrete flooring and/or intermediate floors

The load-bearing capacity must be verified by a structural engineer on the basis of the load per unit area and the resultant distribution of forces in the concrete flooring or intermediate floor.

Ground floor

The load-bearing capacity of the substrate must be verified on the basis of the load per unit area:

Maximum floor pressure: 173 kN/m²



A concrete foundation must be established on native soil if the load-bearing capacity is insufficient!

Foundation data

Concrete quality B 25, ready-mix concrete K 2

Reinforcing bars: BSt. III K - dia. 12 mm

A foundation diagram can be requested if necessary.

Dimensions (without supplementary attachments):

Foundation length: 2492 mm

Foundation width: 1430 mm

Foundation depth: 500 mm



Bottom sump

If the machine is installed in a bottom sump, the convexity of the floor in the area of the bottom sump should not exceed 5 mm at most; if possible, it should be level or concave. If the permitted unevenness is exceeded, the bottom sump may rub against the underside of the machine / machine components.

Machine weight and dimensions



The above weights refer exclusively to the basic machine, i.e. **without** chip conveyor, emulsion tank and workpieces.

Machine weight (kg)	TNA 400
with control cabinet	5600
Machine dimensions (mm)	
Length	4600
Width	1825
Height	2010
Bearing points* (kN)	
A1	15
A2	17
A3	16
A4	14

* Bearing points A see Installation and layout diagrams.

Position of the turret-type tool head

In order to transport the machine, the turret-type tool head must be located in the specified positions so that the transport retainers can be fitted.

Turret-type tool head


X =	Top limit position
Y =	Bottom limit position
Z =	850

Close open hose or pipe lines

To prevent any remaining cutting oil or lubricoolant dripping from the lines, the open hose lines and pipes must be sealed with plugs.

Attach transport retainer

- on the control console
- on the working area door
- between the machine column and Z-slide.



Corrosion protection

Before delivery, all machines are coated to protect them from corrosion. This corrosion protection must be renewed accordingly whenever the machine is subsequently transported again.



Details on corrosion protection can be found in the documentation **Notes on Operating Materials.**

Packaging of the machine, machine components and accessories

- Machine mounted on planks complete with control cabinet.
(The adjusting screws must be removed first.)
- Machine components and accessories mounted on pallets and secured




The following are located in the control cabinet, for example:

- Required records, such as geometry record or safety record
- Installation diagram
- Key for the control console
- Key for the fire protection system
(depending on machine equipment)

The following are located in the chip conveyor, for example:

- Footplates (4x)
- Adjusting screws and locknuts (4x)
- Tools for the operator (such as special wrenches)

Centre of gravity of the machine (S) TNA 400 TX8i-s



Loading and shipping in crate

Machines shipped within Europe are always packed as described on page 23. When shipped to countries with extreme climates, the machine must be protected more extensively during transport. The machines are packed by special packaging companies for shipment to such countries. Only bolted (never nailed) crates are used here.

The period for which protection against corrosion is required must be known. A period of six months is normally assumed. The precise markings depend on the national regulations and customer's specifications.

Machine ready for shipment

Machine mounted on wooden planks and covered with plastic sheeting.

Machine	TNA 400 TX8i-s
• Dimensions LxWxH (mm)	3350 x 2000 x 2100
• Weight (kg)	5600
• Packaging	Planks

Machine in wooden crate	
• Dimensions LxWxH (mm)	3700 x 2100 x 2250
• Weight (kg)	7500
• Packaging	Crate

Chip conveyor	
• Dimensions LxWxH (mm)	4300 x 700 x 1500
• Weight (kg)	500
• Packaging	Pallet

Chip tray	
• Dimensions LxWxH (mm)	4100 x 100 x 850
• Weight (kg)	300
• Packaging	Pallet

Lubricoolant tank	
• Dimensions LxWxH (mm)	1100 x 800 x 950
• Weight (kg)	200
• Packaging	Planks

Packagings are invoiced at cost price. They will be taken back in accordance with the new German regulations on packagings if delivered free of charge to TRAUB.

Transporting the machine with a fork lift truck



Danger due to falling machine / parts

Ensure there is no-one underneath the suspended load!



Beware of tipping over!

The machine must be secured to prevent it tipping over when transported by a fork lift truck!

Note the machine's centre of gravity!

- Non-slip mats should be placed on the fork arms when transporting the machine.
- When setting the machine down, ensure that the fork arms are not tilted, otherwise the planks will break.

Lifting and transporting the machine from the operator side

Fork lift truck requirements

Lifting force, min.	kg	6000
Fork length, min.	mm	1800
Centre of gravity of the load	mm	approx. 1200
Distance of working area door	mm	100

Lifting and transporting the machine from the control cabinet side

Fork lift truck requirements

Lifting force, min.	kg	6000
Fork length, min.	mm	1600
Centre of gravity of the load	mm	approx. 900
Distance of control cabinet	mm	approx. 100

Transporting the machine by crane (min. load capacity 6 t)



Danger due to falling machine / parts

Ensure there is no-one underneath the suspended load!

The machine must not be lifted via the control cabinet!



Beware of being crushed

The installation site must be selected in such a way that there is no risk of anyone or anything being crushed against walls, pillars or hall installations by moving parts or the machine, including manually operated doors and flaps, etc.

Set of hoisting gear and fittings

The complete set of hoisting gear and fittings, Article No. 083199, is available from TRAUB on loan and must be returned **completely and without delay** after use (suspension points see next page).

Suspension points, front view

Shackles must be fitted to the rear ropes and inserted in holes in the transport brackets on the machine column.


Note the arrangement of ropes behind the machine.

The front rope is hooked into the carrier supplied, Article No. 941389.


Round-loop slings E-3-120

Round-loop slings without fitting at the end of the strand

Load capacity	kg	6300
Length of sling		
• Sling 1	mm	3230
• Sling 2	mm	2680
• Sling 3	mm	2290



Shackle, DIN 82101,
carrying capacity 3150 kg




Carrier
Article No. 941389

Transporting the machine by truck

The truck should have pneumatic suspension in order to avoid major bumps during transport!

Example for transporting the machine on a truck



Securing the load



The load must be secured as follows so that it cannot slip.

- **Non-slip rubber mats**


9 mm thick non-slip rubber mats must be placed between the floor and the wooden planks under the four (or six) bearing points of the machine.



The two wooden planks should only rest on the non-slip rubber mats at the outer bearing points of the machine. The wooden planks should not rest on the floor in the middle. If the wooden planks sag in the middle and rest on the floor, non-slip rubber mats must also be fitted there.



- The two wooden planks must be wider than the machine to improve its stability.



- **Diagonal lashing**

The machine must be diagonally lashed to the floor of the truck with suitable straps.



**Danger due to falling machine / parts**

Ensure there is no-one underneath the suspended load!

**Beware of being crushed**

The installation site must be selected in such a way that there is no risk of anyone or anything being crushed against walls, pillars or hall installations by moving parts or the machine, including manually operated doors and flaps, etc.

Remove wooden planks

Remove the two wooden planks which have been screwed onto the machine's four feet.

- Raise machine approx. 200 mm above ground level.
- Steady machine with suitable supports.
- Each wooden plank is connected to the machine with two screws (width across flats 19-M12).
- Unscrew the wooden planks and screw the adjusting screws (in the chip conveyor) into the machine feet (with a protrusion of approx. 50 mm at the bottom).
- Move the machine to its installation position with a crane and place it in the required position.


Installing the machine

- Place the four footplates under the adjusting screws and lower the machine slowly and evenly onto the footplates (remove the guards beforehand if necessary). Ensure that the adjusting screws engage the recesses in the footplates.
- The rear footplates (control cabinet side) must be drilled into place with the dowels provided.

The bar feeding mechanisms and other accessories must be mounted, aligned and anchored in the ground in accordance with the manufacturer's instructions.

Remove transport retainer

- on the control console
- on the working area door
- between the machine column and Z-slide.




Aligning and anchoring the machine



The permissible deviation in longitudinal and transverse direction equals 0.02 mm over 1000 mm.

Place spirit levels on the areas provided.

Longitudinal alignment	Area at the top, on the clamping cylinder
Transverse alignment	Use the fixture Art. No. 090448. Alternatively, place a metal plate on the four machined points of the angle Art. No. 941378 as bearing area.



- Turn the adjusting screws to align the machine lengthwise and crosswise, as well as at the spindle height 1100.



The machine must be adjusted to exactly the **main spindle height of 1100 mm**.


- The rail of the working area door must be located 417 mm above ground level and the feed unit support 820 mm above ground level. These auxiliary dimensions must be maintained in order to ensure the tightness of the machine in combination with the chip conveyor (see drawing).
- The adjusting screws are fixed in position when the necessary accuracy has been obtained. Place washers in position (Article No. 687403), insert and tighten the screws.

Transport and installation of the chip conveyor



Note the manufacturer's user manual

- Transport the chip conveyor to the machine, then lift them off the pallet and set them down with the aid of suitable hoisting gear.
- Remove the accessories and documentation from the chip conveyor if this has not been done already.
- From the operating side, push the chip conveyor under the machine as far as possible, then slide them to the right as far as possible.
- Raise the chip conveyor by means of the four adjustable feet until a horizontal clearance of 30 mm is obtained all-round.
- Remove the plugs from the hose lines and connect the hose lines.
- Connect the lubricoolant pumps to the power supply.



Transport and installation of the lubricoolant unit



Note the manufacturer's user manual

- Transport the lubricoolant unit to the machine, then lift it off the pallet with the aid of suitable hoisting gear.
- Position the lubricoolant unit beside the machine as specified in the layout and installation diagram.
- Remove the plugs from the hose lines and connect the hose lines.
- Connect the lubricoolant pumps to the power supply.

Indicator lamp

Connect the indicator lamp on the machine if removed for transport.

Fuels

Fill with fuels. Refer to chapter **Fuels**.

Switching on the machine



Before switching on the machine, the key-operated switch must be set to **"Production mode"** in order to prevent the machine starting or moving unexpectedly.



Before starting up the machine for the first time, the operator must ensure that the machine and its safety mechanisms are in perfect working order. This must also be checked regularly during normal operation of the machine, but at least whenever it has been repaired or serviced.

- Switch the machine on via the master switch
- Press "NC ON"
- Press "Drives ON"
- Open / close working area door (activate safety function)



The control cabinet may only be opened when the master switch is off and must be locked in accordance with the applicable safety standards whenever the master switch is on.

Notes

- The electrical connections may only be made by duly qualified electricians.
- The electrical documentation supplied is definitive and binding. It must be available to the machine manufacturer's service personnel at all times.
- Potentiometer and switch settings, machine parameters, etc. may only be changed by the machine manufacturer's service personnel.
- The machine must be connected to the power supply via the master switch (multi-wire cable).
It is essential to ensure a clockwise phase sequence when connecting the machine.
- The feeder to the master switch on the control cabinet can be routed from above or through a duct in the base of the control cabinet.
- The control voltages are connected to the PE on one side in accordance with EN 60204 Part 1 (VDE 0113).



Note the information in the circuit diagrams

Overview of fuels



The information in the data sheets of the fluid manufacturers and in the document **Notes on Operating Materials** must be observed during all work involving fuels and fluids.

The filling quantities of the fuels and fluids are stated in the respective fluid schedules.

	Quantity [litres]	Designation	Initial start-up
Central lubrication	1.8	Slideway lubricant CGLP68	Factory-filled by TRAUB
Hydraulic system	70	Hydraulic fluid DIN 51502 HLP(D)32	To be provided by the customer
Lubricoolant unit	275	Cutting oil / emulsion	
Chip conveyor Gear lubrication	Note the manufacturer's user manual		
Bar loading magazine	Note the manufacturer's user manual		



**INDEX-Werke GmbH & Co. KG
Hahn & Tessky**

Plochinger Straße 92
D-73730 Esslingen

Fon +49 711 3191-0
Fax +49 711 3191-587

info@index-werke.de
www.index-werke.de