

# Maintenance Instructions

**TNL32 compact**

## Disclaimer

The illustrations in this documents may deviate from the delivered product. We reserve the right to make changes due to errors or based on technical advances.

## A Word on Copyright

This document is proprietary and was originally written in German. Its reproduction and distribution in whole or in individual parts without permission of the copyright owner is prohibited and will be prosecuted under criminal or civil law. All rights reserved, including for translation.

© Copyright by INDEX-Werke GmbH & Co. KG Hahn & Tessky

## Table of contents

<b>Preface.....</b>	<b>1</b>
General notes.....	1
Safety Instructions.....	1
<b>Service Interval - Care activities.....</b>	<b>7</b>
Maintenance Summary - Care activities.....	8
AL010 - Check the work area door and window pane.....	9
AL011 - Clean the guide rail/gutter at the work area door.....	11
AL027 - Replace the breathing filter at the filler neck of the hydraulic fluid tank.....	12
AL028 - Check hydraulic system (visual inspection) (optional for TNL20.2).....	14
AL044 - Check pneumatic unit (visual inspection).....	16
AL050 - Check the filter mat of the main and counter spindle cooling, clean if necessary.....	19
AL077 - Check fill levels of the fluid tanks.....	20
AL095 - Visual inspection of all fluid lines and electrical cables.....	24
AL120 - Check cooling lubricant (visual inspection).....	25
AL124 - Check the cooling unit and the coolant.....	27
AL147 - Check work area light (visual inspection).....	30
AL165 - Clean and check all telescopic covers and telescopes of the tool carriers.....	31
AL167 - Clean and lubricate clamping device.....	32
AL171 - Clean covers and wipers.....	34
AL180 - Clean the work area.....	35
AL192 - Transition from work area to coolant/oil mist extraction system.....	36
AL240 - Clean the chip tray.....	37
AL266 - Clean the chip conveyor.....	40
AL313 - Lubricate all linear axes by moving the axes.....	41
<b>Service Interval - 2.000 Operating hours.....</b>	<b>43</b>
Maintenance Summary - 2.000 Operating hours.....	44
CL010 - Check maintenance logs of servicing activities.....	45
CL020 - Clean and check wipers and guide rails of the work area door.....	46
CL035 - Check work area door (optionally with electr. drive) and window pane.....	49
CL076 - Checking outer wipers of roller guides on the “workpiece removal unit to the left”.....	53
CL500 - Perform data backup.....	54
CL520 - Check control cabinet.....	55
CL556 - Replace hydraulic fluid filter (optional for TNL20.2).....	56

<b>Service Interval - 4.000 Operating hours.....</b>	<b>59</b>
Maintenance Summary - 4.000 Operating hours.....	60
DL010 - Cleaning of the machine.....	61
DL015 - Check shutters for function and auto stop.....	63
DL020 - Check pressure accumulator (optional for TNL20.2).....	65
DL032 - Check coolant, sacrificial anode, and screen in separate cooling circuit.....	66
DL054 - Check central lubrication unit.....	69
DL058 - Check pneumatic unit.....	71
DL075 - Check the cycloidal gear on the turret and on the front working unit.....	76
DL111 - Check hydraulic system.....	77
DL160 - Determine axis ball screw backlash.....	79
DL170 - Axes.....	81
DL175 - Check the system for reconditioning the cooling lubricant.....	82
DL180 - Check fire extinguishing system (visual inspection).....	83
DL225 - Replace toothed belts and check belt tension.....	84
DL454 - Replacing hydraulic fluid.....	86
DL480 - Check wipers on the guide carts of the workpiece removal unit and replace them, if necessary.....	89
DL486 - Replace wipers.....	90
DL491 - Clean drain holes at the Z cover of the upper tool carrier.....	94
DL494 - Replace wipers and, if necessary, O-ring(s) on sleeve for fixed headstock operation (main spindle).....	95
DL510 - Perform data backup.....	97
DL520 - Check control cabinet and cable assemblies (visual inspection).....	98
DL525 - Check the fan and fan cover in the control cabinet, clean if necessary.....	100
DL590 - Check inspection/replacement date of the backup battery/batteries in the control cabinet (NC).....	101
DL636 - Check the replacement interval of the servo backup batteries at the axis servos.....	103
<b>Service Interval - 8.000 Operating hours.....</b>	<b>105</b>
Maintenance Summary - 8.000 Operating hours.....	106
EL016 - Check the seals on the rotary distributor of the turret and the front working attachment; replace if necessary.....	107
EL030 - Check automatic work area door with Xcenter (option).....	108
EL040 - Replace telescopic plates.....	111
EL042 - Replace profile wiper on main spindle.....	113

<b>Service Interval - 5 Years.....</b>	<b>115</b>
Maintenance Summary - 5 Years.....	116
IL010 - Replacing the pneumatically pilot- controlled cooling lubricant valves.....	117
IL020 - Replace pressure accumulator (optional for TNL20.2).....	118
IL060 - Check the pretension on the spindle bearings on the main and counter spindles.....	120
<b>Service Interval - 8 Years.....</b>	<b>121</b>
Maintenance Summary - 8 Years.....	122
JL005 - Note on replacing the window pane or removing the design pane.....	123
JL010 - Replace the window pane.....	126



## Preface

## General notes

The maintenance activities described in this document essentially pertain only to the machine. Maintenance activities of auxiliary units (e.g., bar loading magazines, extraction systems) are described in the documentation of the specific manufacturer.

The maintenance and servicing activities must absolutely be observed. Failure to conduct maintenance and servicing in accordance with these instructions (especially not at the respective intervals) rules out any claims for damages. This does not apply if it is proved that the non-compliance with the maintenance and servicing activities is unrelated to the defect. Normal wear and tear, especially of components such as bearings and seals, is not a defect. These components are therefore excluded from the warranty. It is recommended to keep a written log of all maintenance activities carried out.

**Maintenance intervals**

The maintenance intervals are given based on the operating hours counter / "Drives On" operating condition.

**Maintenance intervals displayed on the controller (XPanel)**

Depending on the respective machine type and the different controller types, a corresponding message is issued on the controller when a maintenance interval is reached. The maintenance instructions stored on the respective controller provide information (maintenance log) explaining the service and maintenance activities to be performed.

**Cleaning of the machine****Do not clean the machine with compressed air**

- Raised dirt particles may cause breathing difficulty or injury (especially of the sensory organs). Furthermore, raised dirt particles or chips may reach spots where they cause technical problems.

**Do not use cotton waste for cleaning**

- When cleaning with cotton waste, fibers or thread can get loose causing safety problems.

**Solvents**

- Do not use highly volatile solvents such as petroleum spirit, trichloroethylene or similar cleaning agents. These cleaners may damage the seals, which can lead to safety problems.

**Pressure washers**

- Do not clean the machine with a pressure washer. Cleaning with a pressure washer results in strong corrosion. Furthermore, bearings may be degreased, and seals may become leaking, which can lead to safety problems.



## Cleaning of tool mountings

A suitable cleaning tool must be used to clean the hole in the tool mounting.



## Ordering spare parts

Always specify the machine type and machine number when ordering spare parts. This and other information about the machine are located on the type plate under the main switch of the control cabinet.



## Operating fluids

For all work in connection with operating fluids, the information in the data sheets of the respective manufacturers and the information in the document Information on operating fluids must be followed.



## Pressure accumulators $\leq 1$ L

Pressure accumulators with a volume of  $\leq 1$  L are **not** subject to testing and labeling according to the current issue of the pressure equipment directive. The guidelines and regulations applicable in the country of use must be followed.

## Safety Instructions



## Safety Instructions and Technical Details

The user documentation and, in particular, the document “**Safety Instructions and Technical Details**” must be observed.



**Carrying out maintenance work****Authorized and trained personnel**

- Maintenance is to be performed only by authorized and trained personnel. This applies particularly to work on motors (spindle motors) or other electrical assemblies. The instructions in the respective manufacturer documentation must be followed for such work.

**Allow the machine to cool down**

- Prior to working on the machine, it must be allowed to cool down, as hot parts may be located under the covers.

**Maintenance work on machine being switched off**

- In general, maintenance is to be carried out with the machine switched off. The main switch must be locked out. Even when the main switch is switched off, parts of the machine (e.g., the control cabinet light) may still carry electricity. These parts are labeled. In a few cases, maintenance work needs to be performed with the machine turned on (e.g., replacement of backup batteries). These maintenance activities must be carried out with special care.

**Required tools**

- For removing machine parts, suitable lifting gears and a variety of tools must be used. Removed machine parts must be placed in a safe position and secured against falling over.
- All maintenance work on the machine must be carried out with utmost care. Fasteners must be loosened carefully and parts must be secured against falling down. When elastic items (springs) are removed/replaced, appropriate devices must be used. Any (non-horizontal) axes that pose a risk of falling down must be moved to their end positions or secured against falling down. Pedal switches must be put aside to avoid inadvertent actuation.

**Performing maintenance, repair or service work**

- The currently valid safety regulations, as well as the specific manufacturer's information for the intended use must be observed for these activities.

**Use of climbing aids (ladders or steps)**

- In addition, appropriate climbing aids may be required to carry out these activities. When working on climbing aids at great heights, e.g., on the control cabinet, these must always be secured or fastened (depending on the machine, eyelets are also provided for this purpose).



## Procurement/use of spare parts

We recommend the use of original spare parts and accessories. For damages caused by the use of parts from third-party providers, liability and warranty are excluded. The use of such products may change the structural characteristics of the machine and negatively affect active or passive safety.



## Cellular and cordless phones

When the control cabinet is open or the machine covers are open or removed, no cellular or cordless phones may be used within a <2 m radius.



## Coolant

The following must be observed when handling coolants:

When topping up, only the specified coolant ( label on the coolant tank/cooling unit) may be filled in. If there is no label on the container/cooling unit, the coolant already used must be topped up.

The entire cooling system must be carefully cleaned and rinsed several times with clean water before refilling with new coolant.

Mixing different coolants may trigger biological/chemical reactions and cause consequential damage to components.



## Handling hydraulic and hose lines

Damaged hydraulic hose lines must be replaced immediately. Typical types of damage include chafing, kinks, cracks, deformations, or visible leaks.

Flexible, pressurized hydraulic hose lines of **INDEX** equipment are generally designed as thermoplastics or metallic hydraulic hose lines.

The machine operator/owner is responsible for compliance with the laws and regulations of the country of use with regard to the use of hydraulic hoses.

We recommend inspection and documentation of the hydraulic hose lines installed inside the machine and not directly visible every 12 months. For hydraulic hose lines visible in the work area or mounted outside the machine and connecting components to the machine, we recommend inspection and documentation every 6 months.

For the flexible, pressurized hydraulic hose lines used by **INDEX** , empirical values are available for very different periods of use, some of which exceed 10 years.

**Maintenance work on fluid systems (hydraulic, lubrication, and pneumatic systems)**

When carrying out maintenance work on fluid systems (hydraulic, lubrication, and pneumatic systems), make sure **before** starting the work that the respective system has been **depressurized** (accumulator drain valve / manual slide valve).

**Dry run or functional test**

After all maintenance work and work on electrical assemblies, a dry run or functional test must be performed.



## **Service Interval - Care activities**

## Maintenance Summary - Care activities



It is recommended to document the maintenance activities carried out by using the appropriate maintenance log. The maintenance log has the document number DTE098EN - 15.08.2024.



The maintenance interval is highly dependent on the production and environmental conditions of the machine. The determination of the appropriate interval must be made by the operator.

**The maintenance interval should be between once per shift and once a week!**

- AL010** - Check the work area door and window pane
- AL011** - Clean the guide rail/gutter at the work area door
- AL027** - Replace the breathing filter at the filler neck of the hydraulic fluid tank.
- AL028** - Check hydraulic system (visual inspection) (optional for TNL20.2)
- AL044** - Check pneumatic unit (visual inspection)
- AL050** - Check the filter mat of the main and counter spindle cooling, clean if necessary
- AL077** - Check fill levels of the fluid tanks
- AL095** - Visual inspection of all fluid lines and electrical cables
- AL120** - Check cooling lubricant (visual inspection)
- AL124** - Check the cooling unit and the coolant
- AL147** - Check work area light (visual inspection)
- AL165** - Clean and check all telescopic covers and telescopes of the tool carriers
- AL167** - Clean and lubricate clamping device
- AL171** - Clean covers and wipers
- AL180** - Clean the work area
- AL192** - Transition from work area to coolant/oil mist extraction system
- AL240** - Clean the chip tray
- AL266** - Clean the chip conveyor
- AL313** - Lubricate all linear axes by moving the axes.

## AL010 - Check the work area door and window pane

### Orientation

Inspection and maintenance of the work area door includes several steps:

- Inspection of the window pane for damage.
- Check the safety label on the window pane (replacement interval 8 years).
- Check/adjust or replace, if necessary, the wipers.
- Check the work area door for smooth opening/closing.
- Automatic work area door (optional). Hydraulic valves and motor, control panel, rack and spur gear. (for hydraulic door drive)
- Automatic work area door (optional - electric door drive - **follow the manufacturer's documentation** ).

The window pane consists of three panes. The inner pane (inside the work area) of tempered glass, the central pane of polycarbonate, and the outer pane (cover pane) also made of polycarbonate. The inner window pane is relatively resistant. It can be cleaned with any commercially available cleaning agents. Only the center pane is essential for the impact resistance of the window pane.

The polycarbonate panes are subject to **natural** aging and, therefore, must be subjected to regular visual inspection. Through contact with cooling lubricant, the aging process is accelerated even further



If the window pane is damaged, it must be replaced. This is necessary regardless of the extent of damage. Even with minimal damage, the impact resistance of the pane can no longer be guaranteed.

Heavily soiled or damaged wipers may cause damage to the inner pane. Moreover, it may be possible that the work area door can be moved only with considerable effort due to heavy soiling or chip deposits in the wipers.

Check the guide rails of the work area door. The guide bars must be checked and cleaned regularly so that the work area door can be moved without much effort.


### Procedure

1. Check window pane for damage.

2.




The inside of the window pane is scratch-resistant. Any commercial cleaning agent can be used here.



**Example: Window pane TNL20**

- a** Design pane on operator side
- b** Window pane on work area side

Clean window pane on work area side.

3.  Clean the cover pane (outer glass pane) with a soft cloth or sponge and glass cleaner or soap and water. Do not use abrasive or alkaline cleaners (e.g., benzene, acetone or carbon tetrachloride) and no sharp tools or sharp objects (such as razor blades or screwdrivers).

Clean cover pane.

4. Check wipers. Remove and clean the wipers. If the wipers are severely deformed or damaged, they must be replaced. To clean the door panels evenly, be sure to reinstall the wipers after their removal aligned in parallel and ensure that they snugly contact the work area door.
5. Check the work area door for ease of movement. To do so, open and close the work area door. If the work area door can be moved only with effort, determine the cause. Possible causes include – depending on the design of the work area door – defective or improperly adjusted wipers. Chips on the guide bar or between the door and wiper, or in the guide rollers of work area door.




**AL011** - Clean the guide rail/gutter at the work area door


## Orientation

The guide rail/gutter located at the underside must be cleaned regularly around the work area door.

## Procedure



Example: Exterior view of guide rail/gutter TNL20



Example: Inside cover sheets, guide rail/gutter TNL20

Clean guide rail/gutter at the work area door.

In case of heavy soiling, 2 cover sheets can be removed at the inside for better cleaning, and the dirt can be pushed into the chip conveyor.

## AL027 - Replace the breathing filter at the filler neck of the hydraulic fluid tank.

### Orientation



The breathing filter on the oil filler neck of the oil tank must be regularly replaced depending on the ambient conditions.



Due to different requirements and/or specifications of the respective manufacturers, be sure to review the respective manufacturer's documentation!



Filters are hazardous waste and must be disposed of in a controlled manner.

### Requirement

It is essential to keep the filter described here in stock. **It is not permitted to owner the machine without this filling and breathing filter.**



Use only the original filters according to the spare or wear parts list.



Only filters with retained particle sizes described in the fluid plans must be used.

## Procedure

1.



Example: Filling and breathing filters of hydraulic and lubrication systems (by ARGO-HYTOS GmbH)

Replace breathing filter.

## AL028 - Check hydraulic system (visual inspection) (optional for TNL20.2)

### Orientation


To ensure trouble-free operation, periodic checks of the oil level are necessary. The fill level must be between the upper and lower marks on the oil sight glass.



Only use hydraulic fluid grade 15/13/10 in accordance with ISO 4406. Viscosity other than 32 according to DIN ISO 3448 is not admissible.



For all work in connection with operating fluids, the information in the data sheets of the respective manufacturers and the information in the document **Information on operating fluids** must be followed.




**Example: Hydraulic unit TNL32 compact**

- 2a** System pressure display
- 2b** Hydraulic fluid filler neck
- 2c** Hydraulic fluid fill level indicator
- 2d** Hydraulic fluid filter/filter cartridge
- 2e** Electronic contamination indicator
- 2f** Accumulator drain valve
- 2g** Hydraulic fluid temperature display
- 2h** Metal filter
- 2i** Pressure accumulator
- 2j** Safety valve



Screws on the hydraulic system, the connected components, and the supply lines must be tightened to the manufacturer's specified torques.

## Procedure

1.  The hydraulic fluid level should always be near the top mark when the machine is switched off. During production, the oil level may drop after several consumers have been connected.

Check oil level at the oil sight glass.

2. Visual inspection of the hydraulic fluid. The hydraulic fluid may not exhibit any foaming or cloudiness at the oil sight glass. In case of problems of this kind, immediately determine the cause and correct the error. If in doubt, take a sample for analysis and contact the manufacturer of the hydraulic fluid.
3. Check pressure setting on pressure gauge and adjust if necessary. The value to be checked here is specified (see hydraulic diagram) and should be between 70-80 bar.
4. Check supply and fluid lines (damage and leakage). Supply and fluid lines must be checked for damage. Pre-damage such as kinks or abrasions should be logged and replacement should be initiated.

## AL044 - Check pneumatic unit (visual inspection)


### Orientation

The pneumatic unit is composed of the two System Part (1a-1h) and Linear Measuring System (1i-1n) components. To ensure trouble-free operation, periodic checks (visual inspection) of the pneumatic unit are necessary.

- Check oil level at oiler (optional).
- Check system pressure and sealing air settings.
- Check fluid lines.
- Drain condensate (not applicable to auto-drain).
- Check pressure setting on the differential pressure monitoring gauge.



Due to different requirements and/or specifications of the respective manufacturers, be sure to review the respective manufacturer's documentation!



**Pneumatic system unit TNL32 compact**

- 1a** Manual switch-on valve
- 1b** Filter regulating valve / system pressure gauge 6 bar
- 1c** Filter insert 40 µm
- 1d** Filter insert 5 µm
- 1e** Branch module with system pressure sensor
- 1f** Electrical turn-off valve
- 1g** Branch module for functions
- 1h** Pressure regulating valve for sealing air
- 1i** Distribution block
- 1j** Filter insert 1 µm
- 1k** Filter insert 0.01 µm
- 1l** Activated carbon
- 1m** Pressure regulating valve/pressure sensor
- 1n** Differential pressure sensor for linear measuring system
- 1o** Differential pressure sensor for linear measuring system

## Procedure

1. Check oil level at oiler (optional).
2. Check the pressure setting on System Pressure and Sealing Air pressure gauges, and adjust if necessary. A system pressure of 6 bar and a sealing air pressure of 1 bar are set at the factory.
3. Check fluid lines (damage and leakage). Fluid lines must be checked for damage. Pre-damage such as kinks or abrasions should be logged and replacement should be initiated.
4. Drain condensate (not applicable to auto-drain).

5. Check the pressure setting on the “linear measuring system” pressure sensor and adjust if necessary. An operating pressure of 1 bar has been set at the factory.



**AL050** - Check the filter mat of the main and counter spindle cooling, clean if necessary

## Orientation

The filter must be cleaned regularly depending on the ambient conditions.




Use only the original filters according to the spare or wear parts list! Otherwise the machine is at risk of sustaining serious damage due to overheating.



Follow the corresponding manufacturer's documentation.

## Procedure

1.



Example: Filter mat of spindle cooling, left side of the machine, TNL32 compact

Remove left side panels.

2. If necessary, clean the filter mat according to the manufacturer's instructions.
3. Attach the left side panels again.

### AL077 - Check fill levels of the fluid tanks

#### Orientation

To ensure the operational safety of the machine, the fill levels of all fluid tanks must be regularly checked, and topped off if necessary.

Working media, such as hydraulic fluids, cooling lubricants, lubricating greases/oils, are also subject to degradation or aging like the components involved in this process, and must therefore be serviced, topped up or changed at regular intervals. Do not use cotton waste and highly volatile solvents such as petroleum spirit, trichloroethylene or similar cleaning agents. The machine must not be cleaned with compressed air. To ensure trouble-free operation, periodic checks of the oil level are necessary.

The hydraulic fluid and lubricating oil levels should always be near the top mark when the machine is switched off. During production, the oil level may drop after several consumers have been connected.

The interval for this maintenance activity is strongly dependent on the operating profile of the machine. If the machine is used in three-shift operation, this maintenance activity must be carried out much more frequently.

#### Requirement



For all work in connection with operating fluids, the information in the data sheets of the respective manufacturers and the information in the document **Information on operating fluids** must be followed.




Due to different requirements and/or specifications of the respective manufacturers, be sure to review the respective manufacturer's documentation!

#### Procedure

1.



Only oil of viscosity class ISO VG 220 must be used to lubricate the TNL20.2 and TNL32 compact.



**Example: Central lubrication\_TNL32 compact**

- 1 Central lubrication unit
- 2 Lubricating oil level indicator
- 3 Lubricating oil filler neck
- 4 System pressure display


Check fill level of the central lubrication unit, top up if necessary.

2.



Only use hydraulic fluid grade 15/13/10 in accordance with ISO 4406.


Viscosity other than 32 according to DIN ISO 3448 is not admissible.



**Example: Hydraulic unit TNL32 compact.**

- 2a** System pressure display
- 2b** Hydraulic fluid filler neck
- 2c** Hydraulic fluid fill level indicator


Check fill level at hydraulic fluid tank.



**Example: Cooling lubricant tank (Bürener), TNL32 compact.**

- 1 Cooling lubricant fill level indicator
- 2 Cooling lubricant filler opening

Check level of cooling lubricant tank, top up if necessary.



**Example: Liquid-air cooling system TNL32 compact**

- 1 Coolant fill level indicator
- 2 Coolant filler opening

Check fill level of coolant tank in separate cooling circuit, top up if necessary (optional).

### AL095 - Visual inspection of all fluid lines and electrical cables

#### Orientation

Depending on the duration of use, usage profile of the machine and different ambient conditions, it is absolutely necessary to subject all fluid lines and electrical cables to regular visual inspections. This allows that any faults or problems can be detected and eliminated early on.



Damaged fluid lines may cause leakage of fluids under high pressure. Be sure to use personal protective equipment during visual inspection.

#### Requirement

Should defective points be found on fluid lines or electrical cables during the visual inspection, the machine must be switched off and the damaged lines or cables must be promptly replaced.



Replaced fluid lines must be tightened to the torque specified by the manufacturer.

#### Procedure

1. Visual inspection of all fluid lines.
2. Visual inspection of all electrical cables.

## AL120 - Check cooling lubricant (visual inspection)

## Orientation



Follow the user documentation **Notes on Working Media** and the documentation of the cooling lubricant manufacturer.



For all work in connection with operating fluids, the information in the data sheets of the respective manufacturers and the information in the document **Information on operating fluids** must be followed.

The cooling lubricant is subject to wear depending on the material and the generated temperature. Regular inspection is therefore essential.

In case of strong formation of odor, fungus or mold, the cooling lubricant emulsion must be changed at once. The principle of open lubrication may cause a slight commixture between cooling lubricant and hydraulic fluid. If the surface of the cooling lubricant tank is covered with a layer of oil, the cooling lubricant must be replaced. Furthermore, determine the cause of the oil ingress.



Synthetic cooling lubricants or cooling lubricant based on esters are not admissible.

If the type of cooling lubricant or the manufacturer is changed, make sure that the cooling lubricant meets the required specifications.

See the manufacturer's documentation for the fill quantities.



Regularly checking the cooling lubricant is necessary in particular if cooling lubricant emulsions containing mineral oil are used, so that the required properties are ensured.

## Requirement

A refractometer is required to determine the concentration.

## Procedure

1.



Caution

**Biological and chemical changes in the cooling lubricant.**

**Skin irritation or respiratory and circulatory problems.**

Wear personal protective equipment (e.g., safety gloves and safety goggles).

Remove a cover (e.g., at the strainer basket) on the chip tray or the chip conveyor.

2. Visual and olfactory inspection of the cooling lubricant.

3. Check cooling lubricant emulsion. See document **Notes on working media**

4. Check fluid lines. Fluid lines must be checked for damage. Pre-damage such as kinks or abrasions should be logged and replacement should be initiated.



**AL124** - Check the cooling unit and the coolant

## Orientation


For add-on equipment that cannot be cooled conventionally with cooling lubricants or hydraulic fluid due to high temperature development, separate cooling is provided in an independent cooling circuit. The coolant used here must be checked continuously for its condition like other coolants. Also perform a visual inspection of the cooling unit and the supply and fluid lines as part of the servicing and maintenance activities. Check for leaks on the system in general as well as at screw connections, and supply and fluid lines.



This visual inspection or monitoring requires no specific knowledge of refrigeration according to the manufacturer's documentation. These activities can be carried out by instructed individuals with appropriate expertise.




Due to different requirements and/or specifications of the respective manufacturers, be sure to review the respective manufacturer's documentation!



**Example: Internal machine cooling FWKS TNL32 compact**

- 1 Fill level indicator
- 2 Level sensor
- 3 Water-glycol mixture filler neck
- 4 Cooling unit supply line screen
- 5 Blanking plug/tank drain valve
- 6 Water-glycol mixture PID controller
- 7 Coolant inlet flow at customer's site (water/water-glycol mixture)
- 8 Coolant return flow at customer's site
- 9 Control cabinet cooling
- 10 Main spindle cooling
- 11 Counter spindle cooling



Example: Internal machine cooling FWKS TNL32 compact

- 1 Fill level indicator
- 2 Level sensor
- 3 Water-glycol mixture filler neck
- 5 Blanking plug/tank drain valve
- 10 Main spindle cooling
- 11 Counter spindle cooling



The machine is filled with a concentration of Antifrogen N (34% glycol) at the factory.

## Requirement



Top up only coolant of the same manufacturer having the same specification. Mixing different coolants may lead to corrosion of the cooling system, incompatibility and degradation of the coolant. **Be sure to observe the specified concentration of glycol in the respective machine.**



Be sure to replenish with a ready-mix. Mixing different glycol alkalis may trigger chemical reactions causing agglutination or clumping of the coolant.



When switching the coolant to another product or changing the manufacturer, the cooling system must be completely flushed and cleaned with this coolant. When preparing the coolant from concentrate and water, be sure to use demineralized water only. Only then the machine may be put back into operation.

## Procedure

1. Check coolant. Test criteria for this visual inspection are the clarity and transparency of the coolant.
2. Check fill level on the level indicator.

## AL147 - Check work area light (visual inspection)


### Orientation

To ensure even illumination of the working areas in the machine, work area lights are installed in the work area.

They enable safe working and should therefore be checked regularly. **Damaged lighting fixtures must be replaced immediately.**

### Procedure

1. Check all lamps (visual inspection).
- 2.



Example: Work area light TNL20

Check lamp protective glass for damage. If cooling lubricant has already penetrated into the lamp protective glass of the work area light, the lamp must be repaired.

## AL165 - Clean and check all telescopic covers and telescopes of the tool carriers

### Orientation

Depending on the material used and the machining process, the telescopic cover must be cleaned and checked regularly. In particular, before any prolonged shutdown of the machine (e.g., during weekends).



After cleaning, the telescopic covers and wipers must be coated with low-viscosity oil.

The oil must not resinify and sediments must not form when exposed to other working media or machining residues (e.g., metallic dust). Otherwise, the service life of the wipers would be considerably impaired.

### Requirement

When cleaning the telescopic cover and telescope of TC top and TC bottom, the tool carriers must be moved to a suitable position.

### Procedure

1. Clean telescopic cover.
2. Flush plates with cooling lubricant.
3. Check the plates for visible damages (e.g., dents or flaws). Have damaged plates repaired or replaced immediately by the machine manufacturer's service personnel.
4. Apply thin oil to telescopic plates by spraying or rubbing.
5. Carefully move tool carriers back and forth; if necessary, spray or rub once more with oil.

### AL167 - Clean and lubricate clamping device

#### Orientation

To ensure reliability and accuracy of the machine, clamping devices must be subjected to periodic maintenance.

The interval of this maintenance is strongly influenced by the type of material and daily production time. Especially for short chipping materials (e.g., brass or cast iron), these maintenance activities must be performed much more frequently.

Compression collets and guide bushings must be removed for cleaning.

Note when removing the compression collet from the main spindle:

- Fixed headstock operation → remove in work area
- Sliding headstock operation → remove in drive area




Due to different requirements and/or specifications of the respective manufacturers, be sure to review the respective manufacturer's documentation!



Depending on the materials to be machined (e.g.: brass, cast iron) and the number of shifts per day, more frequent cleaning of the clamping device is necessary.

For this, the clamping device must be removed and completely cleaned.

#### Requirement



Example: Collet and chuck.



**Do not use cotton waste for cleaning.**

When cleaning with cotton waste, fibers or thread can get loose causing safety problems.

## Procedure

1.

**Sharp contours on the clamping device****Cuts**

Use personal protective equipment (e.g., protective gloves)



To **remove/install the compression collet and guide bush**, see the documentation "Operating the Machine TNL20" or "Structure and Features of the Machine TNL32 compact".

Clean clamping devices

2. Lubricate clamping devices according to manufacturer's instructions.

### AL171 - Clean covers and wipers

#### Orientation

Depending on the material used and the machining process, the covers and wipers must be cleaned and checked regularly. In particular, for dry machining and before any prolonged shutdown of the machine (e.g., during weekends).

Dirty covers and wipers affect the accuracy of the machine and its service life.

Contamination of the covers and wipers results in increased friction (stiffness) of the plates. This may damage the covers and wipers so that contaminants can get into the area behind the cover. This in turn may cause damage to other machine parts, requiring expensive repair. In the event of damage, determine the cause of the damage and immediately notify the machine manufacturer or its representative company.



After cleaning, the cover must be coated with low-viscosity oil.

The oil must not resinify and sediments must not form when exposed to other working media or machining residues (e.g., metallic dust). Otherwise, the service life of the wipers would be considerably impaired.

#### Requirement

Before starting the cleaning, move the tool slides to positions that are more convenient for the cleaning process.



Power off the machine and secure it against power on.

#### Procedure

1. Clean cover panels. Remove chips with a suitable chip hook or hand-held broom. Afterwards rub with a cloth.
2. Check covers and wipers for damage. Look for deep scoring or abrasion.
3. Oil covers.
4. Switch the machine on and move the tool slides until an even film of oil is visible over the whole traversing range of the covers. If relubrication is required, first stop the travel movement and set the feed rate override switch to the “zero” position.



## AL180 - Clean the work area

### Orientation

To ensure consistent quality, high availability and value retention, the machine must be regularly cleaned, depending on the operating conditions.

Of course, this is influenced by various factors. The use of emulsion as a cooling lubricant requires a more frequent and intensive cleaning.

Compared to machining producing long chips, machining producing short chips requires a considerably higher maintenance effort. Short chips, such as in the machining of brass or cast iron, form chip accumulations or become deposited in small cracks and corners. These positions must be cleaned regularly to avoid damage to the respective components.

Areas such as telescopic covers, rubber seals, sealing lips or wipers are particularly affected points. Frequent cleaning of these areas is particularly important.

### Requirement



Only the working media described in the documentation may be used for the cleaning of the machine and after-treatment.

Always use the proper tool to remove chips.

The following tools are required for cleaning:

- chip hooks,
- chip brushes,
- spray bottles of cleaners or cooling lubricant,
- a sufficient quantity of rags,
- the used medium, cooling lubricant to apply to the telescopic plates and all other bare parts by spraying or by brushes.

### Procedure

1.



Caution

#### **Chips and projecting tools in the work area.**

##### **Cuts.**


Use of personal protective equipment such as safety goggles and gloves, and appropriate tools.

Remove chips from the work area.

2. Chip accumulation particularly in the area of the tool carriers and the work area door.
3. Flush work area with cooling lubricant.
4. Wipe clean with rags.
5. Apply an oil film to bare metal plates and telescopic covers.
6. Examine any visible damage, and repair or replace, if necessary.

## AL192 - Transition from work area to coolant/oil mist extraction system

### Orientation



Example: Extraction from work area TNL32 compact,

The transition from the work area to the coolant/oil mist extraction system is provided with a cover that is open at the top to protect against chips. Accumulated cooling lubricant is removed by means of a return flow (hose) outside the drive compartment (behind the cover) into the chip conveyor/chip tray. The cover and the return flow (hose) behind the cover must be checked for contamination at regular intervals, and cleaned if necessary.

### Procedure

1. Check the cover and drain area with return flow (hose) for contamination, and clean if necessary.

**AL240** - Clean the chip tray

## Orientation



Avoid skin contact with cooling lubricant! Use appropriate skin protection agents!...



For all work in connection with operating fluids, the information in the data sheets of the respective manufacturers and the information in the document **Information on operating fluids** must be followed.




Follow the corresponding manufacturer's documentation.



Removing the chips is allowed only when the machine is switched off or in setup mode.


To ensure a smooth production process, the chip tray should be cleaned and serviced regularly. The cleaning interval depends on the utilization of the machine. The chip tray is used for collection of chips from the work area and is also a reservoir for the cooling lubricant. In particular, make sure that the area around the cooling lubricant pump(s) is always free of chips or dirt.



Example: TNL20 chip tray

## Procedure

1.




Example: TNL20 chip tray cover

Open the 2 quick releases on the cover. Lift the cover at the upper handle and take it off using the second handle.

2. If necessary, push the chips from the machine area to the chip pusher (a).

3.



Example shown

Use the chip pusher (a) to push the chips to the storage/drip position (b) and allow the cooling lubricant to drain.

4. Then deliver the chips into a suitable container using the chip pusher.

5. Replace the cover and fasten it with the 2 quick releases.

## AL266 - Clean the chip conveyor

### Orientation



Service and maintenance are to be carried out according to the manufacturer's specifications.



For all work in connection with operating fluids, the information in the data sheets of the respective manufacturers and the information in the document **Information on operating fluids** must be followed.

### Requirement

To ensure a smooth production process, the chip conveyor should be cleaned and serviced regularly. With regular cleaning, any defects can be detected and corrected early. The chip conveyor is used for removing the produced chips from the work area. The cooling lubricant is filtered in the chip conveyor. For this purpose, various filters and filter plates are built into the chip conveyor. These filters must be cleaned regularly.



Be sure to interrupt the motion of the conveyor belt by switching off the chip conveyor before commencing cleaning work around the discharge chute!

### Procedure

1. Perform service and maintenance activities on the chip conveyor according to the manufacturer's instructions

**AL313** - Lubricate all linear axes by moving the axes.

## Orientation


Move all linear axes through the maximum travel stroke to ensure uniform lubrication of the linear guides.

## Procedure

1.



When moving the axes, be sure to pay attention to the collision zones with other spindles, tool carriers and tools.



Example: TNL32-11 compact

Lubricate all linear axes by moving the axes.





## **Service Interval - 2.000 Operating hours**

## Maintenance Summary - 2.000 Operating hours



It is recommended to document the maintenance activities carried out by using the appropriate maintenance log. The maintenance log has the document number DTE098EN - 15.08.2024.

- CL010** - Check maintenance logs of servicing activities
- CL020** - Clean and check wipers and guide rails of the work area door
- CL035** - Check work area door (optionally with electr. drive) and window pane
- CL076** - Checking outer wipers of roller guides on the "workpiece removal unit to the left"
- CL500** - Perform data backup
- CL520** - Check control cabinet
- CL556** - Replace hydraulic fluid filter (optional for TNL20.2)

## **CL010** - Check maintenance logs of servicing activities

### Orientation

The maintenance logs on the performed maintenance activities allow you to review the maintenance activities carried out between two maintenance intervals. The logs may contain important indications as to work that may be necessary beyond the maintenance activities. Similarly, the logs can be used for determining the cause of malfunctions due to incorrect or inadequate maintenance activities carried out.

### Procedure

1. Check maintenance or inspection logs.

## CL020 - Clean and check wipers and guide rails of the work area door

### Orientation



Regular inspection of the wipers prevents damage to the wipers themselves and to the work area door.

If the work area door can be opened and/or closed only with increased effort, it can be expected that the wipers are already destroyed by accumulation of chips and swarf compaction.

### Requirement



Example: Chip hook and chip brush

Use appropriate tools to remove coarse chips, chip nests and other debris.

### Procedure



Example: 1 Removing chip nest using appropriate tools (e.g., chip hooks)

Remove large chips on the inside of the work area door from top to bottom. Use a chip hook for this purpose.



Example: 2 Sweep small chips and other debris from top to bottom using chip brooms or brushes.

Remove small chips and chip accumulations on the inside of the work area door from top to bottom. Use a chip brush for this purpose.





Example: 3 upper wipers, G300

Clean wipers.

**Alternatively, the following procedure can be used!**

In case of heavy soiling or adhesion of chips to the wipers, the wipers and associated cover panels should at any rate be completely removed and cleaned. **In this case, also clean the area behind the wipers.**

- 4.
- 
- Make sure that the wipers evenly contact the work area door before tightening the screws.



Example: 4 wipers on the sides and bottom, G300

Check the wipers for proper seating. After the work area door has been cleaned, it should open and close again without much effort as usual

5.



If cleaning or replacement of the wipers has not resulted in tangible improvement, the soiled rollers and the guide rail of the work area door must also be cleaned.

Clean rollers and guide rail of the work area door.

## CL035 - Check work area door (optionally with electr. drive) and window pane

### Orientation

Inspection and maintenance of the work area door includes several steps:

- Inspection of the window pane for damage.
- Check the safety label on the window pane (replacement interval 8 years).
- Check/adjust or replace, if necessary, the wipers.
- Check the work area door for smooth opening/closing.
- Check functions of the automatic work area door (optional - electric door drive - **Follow manufacturer's documentation from Langer & Laumann** ).

The window pane consists of three panes. The inner pane made of tempered glass, the central pane made of polycarbonate, and the outer pane also made of polycarbonate. The inner pane is relatively resistant. It can be cleaned with any commercially available cleaning agents. Only the center pane is essential for the impact resistance of the window pane.

The polycarbonate panes are subject to **natural** aging and, therefore, must be subjected to regular visual inspection. Through contact with cooling lubricant, the aging process is accelerated even further.



If the window pane is damaged, it must be replaced. This is necessary regardless of the extent of damage. Even with minimal damage, the impact resistance of the pane can no longer be guaranteed.

Heavily soiled or damaged wipers may cause damage to the inner pane. Moreover, it may be possible that the work area door can be moved only with considerable effort due to heavy soiling or chip deposits in the wipers.

Regularly check and clean the guide rails of the work area door.

Check function of the automatic work area door with electric drive (option like open/close) with different speeds with or without obstacle detection check.

### Requirement



The automatic work area door can be tested only when the machine is switched on and fully functional.

Be sure that the wipers have been checked before testing the automatic work area door. Be sure to remove any chip nests and make sure that the wipers have been cleaned and attached to the plates.

### Procedure

1. Check window pane for damage.



2.




Clean the outer pane with a soft cloth or sponge and glass cleaner or soap and water. Do not use abrasive or alkaline cleaners (e.g., benzene, acetone or carbon tetrachloride) and no sharp tools or sharp objects (such as razor blades or screwdrivers).

Clean outer pane.

3. Clean inner pane.

4.




**Example: Safety label – window pane 2006**

- 1 Year of manufacture
- 2 Protection class and EN standard
- 3 Manufacturer
- 4 INDEX part number

Check safety label (replacement interval every 8 years).

5. Check wipers. Remove and clean the wipers. If the wipers are severely deformed or damaged, they must be replaced. To clean the door panels evenly, be sure to reinstall the wipers after their removal aligned in parallel and ensure that they snugly contact the work area door.

6.



**Example: Automatic work area door with drive**



Check the work area door for ease of movement. To do this, press the EMERGENCY STOP button and manually open and close the work area door. If the work area door can be moved only with effort, determine the cause. Possible causes are defective or improperly adjusted wipers, or chips on the guide bar or in the guide rollers of the work area door.

7.



Danger

#### Pinching of limbs due to faulty obstacle detection on the work area door

Check obstacle detection.




INDEX recommends an annual check of the obstacle detection function of the automatic work area door.

The check should only be carried out using a suitable aid, e.g., a rectangular strip or a softwood squared timber.

INDEX recommends documenting the results of the inspection and keeping them at the workplace.

The machine must be switched on and fully functional for this test.



Example: Checking the obstacle detection

Check obstacle detection of the automatic work area door. During the obstacle detection test, a rectangular strip or softwood squared lumber, for example, is held in the travel path of the work area door during the closing process. If the rectangular strip or squared timber comes into contact with the work area door in the closing area, the obstacle detection is triggered and the closing movement must be reversed.


If the obstacle detection does not immediately lead to reversal of the moving direction, the complete work area door must be checked immediately. **The machine must not be operated any further.**

8.



Be sure to contact the **INDEX** service department or an **INDEX** representative.

9.



**Example: Automatic work area door drive**

- 1 Drive/deflection pulley
- 2 Belt
- 3 Driver
- 4 Deflection pulley

Visual inspection of the drive of the automatic work area door. This is in particular an assessment of the toothed belt (2) - condition, tension. Also the condition of the two deflection pulleys (1+4) and the actuator (3).

## CL076 - Checking outer wipers of roller guides on the “workpiece removal unit to the left”



Carrying out the maintenance activities described below requires special knowledge. For this reason, these maintenance activities must only be carried out by staff that has received adequate training by the machine manufacturer!

### Orientation

Regularly checking the wipers of the roller guides on the “workpiece removal unit to the left” prevents accelerated wear of the guides. This test is a visual inspection. But if the wiper is destroyed and no longer snugly contacts the contour of the guide, it must be replaced. **It is essential to ensure absolute cleanliness when removing and installing the wiper.**

### Requirement

Move the “workpiece removal unit to the left” to a suitable position. For checking the outer wipers, parts of the machine enclosure may have to be removed from the machine. In most cases, access to the wipers is best in the end positions of the respective axes. To move to the positions in which the wipers can be checked, it may be necessary to switch the machine on/off several times.

### Procedure

1. Move the “workpiece removal unit to the left” to the position required for checking.

2.



Caution


#### Moving axes.

#### Crushing hazard.

Switch off the machine via the main switch or shut down with the EMERGENCY STOP button.

Remove relevant machine enclosure.

3.



Example: Wiper on the guide cart of the roller guide (view from the preassembly).

Check wipers.

4. Replace wipers. Loosen and remove the mounting screws of the wiper on the guide cart. Push the wiper from the guide bar. Clean the guide bar and push a new wiper onto the guide bar. Finally lightly oil the guideway.

## CL500 - Perform data backup

### Orientation

Using a current data backup, the machine can be restored to the original state before the failure after a defect of the internal storage device/NC control.

The file name of the data backup includes the machine type, machine number, and date/time of the backup.




Network settings and the customer's NC programs are not included in the backup.

Backup additionally to an external data carrier for access in case of a defect of the internal storage medium.

### Procedure

1. Connect USB device to USB port

- 2.



Example shown

Open **IN/OUT** screen and use **TAB** to activate the right part of the screen

3. Press **Softkey** Select (F3) (select appropriate target, e.g., USB)
4. Press **Softkey** Menu (F8) twice. Softkey text "Menu 3-3" appears

- 5.



Note that the backup includes no customer NC programs! Include them in a separate backup, if necessary

Press **Softkey** Backup (F1) and press **Softkey** OK (F1) to acknowledge the informational message

All relevant parameters and data for the backup are compiled

6. Press **Softkey** OK (F1) to confirm the transfer of the data to the desired storage location

## CL520 - Check control cabinet

### Orientation

To avoid problems and prevent any resulting system failures, simplified control cabinet checks must be carried out at regular intervals on the cabinet and associated components. Additional built-in air conditioning units (option) ensure a constant temperature in the control cabinet. These air conditioners cannot work efficiently if filters are dirty or doors are not tight.

### Procedure

1.

**Electric shock**

Power off the machine and wait approx. 30 minutes. Check with a meter if there is still voltage applied to the intermediate circuit.

Check settings of the fuses. For this purpose, review the information in the wiring diagram.

2. Check the screws of drives, terminals, control modules, connectors, bus, device bus and intermediate circuit bus for tightness.

3.



Due to different requirements and/or specifications of the respective manufacturers, be sure to review the respective manufacturer's documentation!

If necessary, check settings on the air conditioning unit(s).

4. Clean suction port(s).
5. Check condensate drain.
6. Check door seals.

## CL556 - Replace hydraulic fluid filter (optional for TNL20.2)



Carrying out the maintenance activities described below requires special knowledge. For this reason, these maintenance activities must only be carried out by staff that has received adequate training by the machine manufacturer!

### Orientation

One or more hydraulic fluid filters are installed on the machine depending on the product and its equipment. The filters are provided with a sensor that signals malfunction or contamination to the control. If a fault is displayed on the control, the filter unit should be removed or replaced.



For all work in connection with operating fluids, the information in the data sheets of the respective manufacturers and the information in the document **Information on operating fluids** must be followed.

### Requirement



Only filters with retained particle sizes described in the fluid plans must be used.



Use only the original filters according to the spare or wear parts list.


A suitable container should be ready for the disposal of the filter and the residual oil in the filter bowl.

### Procedure

1.



Power off the machine, depressurize the hydraulic system by opening the accumulator relief valve(s), and protect against accidental power on.



**Example: Hydraulic fluid filter TNL32 compact**

- 2a System pressure display
- 2c Hydraulic fluid fill level indicator
- 2d Hydraulic fluid filter/filter cartridge
- 2e Electronic contamination indicator
- 2f Accumulator drain valve

Using a wrench, loosen the filter bowl (**Y**) and remove it from the filter unit (**X**).

2.



Filters are hazardous waste and must be disposed of in a controlled manner.



Z

**Example: Filter insert (Z)**

Empty filter bowl (**Y**) into prepared container. **Do not fill fluid from the filter bowl (Y) back into the tank!** Remove filter (**Z**).

3. Clean filter bowl (**Y**) and insert a new filter (**Z**). Reinstall the filter bowl **and tighten by hand until it stops**. Then back off the filter bowl 1/8 turn.





## **Service Interval - 4.000 Operating hours**

## Maintenance Summary - 4.000 Operating hours



It is recommended to document the maintenance activities carried out by using the appropriate maintenance log. The maintenance log has the document number DTE098EN - 15.08.2024.

- DL010** - Cleaning of the machine
- DL015** - Check shutters for function and auto stop
- DL020** - Check pressure accumulator (optional for TNL20.2)
- DL032** - Check coolant, sacrificial anode, and screen in separate cooling circuit
- DL054** - Check central lubrication unit
- DL058** - Check pneumatic unit
- DL075** - Check the cycloidal gear on the turret and on the front working unit
- DL111** - Check hydraulic system
- DL160** - Determine axis ball screw backlash
- DL170** - Axes
- DL175** - Check the system for reconditioning the cooling lubricant
- DL180** - Check fire extinguishing system (visual inspection)
- DL225** - Replace toothed belts and check belt tension
- DL454** - Replacing hydraulic fluid
- DL480** - Check wipers on the guide carts of the workpiece removal unit and replace them, if necessary
- DL486** - Replace wipers
- DL491** - Clean drain holes at the Z cover of the upper tool carrier
- DL494** - Replace wipers and, if necessary, O-ring(s) on sleeve for fixed headstock operation (main spindle).
- DL510** - Perform data backup
- DL520** - Check control cabinet and cable assemblies (visual inspection)
- DL525** - Check the fan and fan cover in the control cabinet, clean if necessary
- DL590** - Check inspection/replacement date of the backup battery/batteries in the control cabinet (NC)
- DL636** - Check the replacement interval of the servo backup batteries at the axis servos.

## DL010 - Cleaning of the machine

### Orientation

To ensure consistent quality, high availability and value retention, the machine must be regularly cleaned, depending on the operating conditions.

Of course, this is influenced by various factors. The use of emulsion as a cooling lubricant requires a more frequent and intensive cleaning.

Compared to machining producing long chips, machining producing short chips requires a considerably higher maintenance effort. Short chips, such as in the machining of brass or cast iron, form chip accumulations or become deposited in small cracks and corners. These positions must be cleaned regularly to avoid damage to the respective components.

Areas such as telescopic covers, rubber seals, sealing lips or wipers are particularly affected points. Frequent cleaning of these areas is particularly important.

### Requirement



Only the working media described in the documentation may be used for the cleaning of the machine and after-treatment.

Always use the proper tool to remove chips.

The following tools are required for cleaning:

- chip hooks,
- chip brushes,
- spray bottles of cleaners or cooling lubricant,
- a sufficient quantity of rags,
- oil to apply to the telescopic plates and all other bare parts by spraying or by brushes.

### Procedure

1.



Caution

#### **Chips and projecting tools in the work area.**

#### **Cuts.**

Use of personal protective equipment such as safety goggles and gloves, and appropriate tools.

Remove chips from the work area.

2. Chip accumulation particularly in the area of the tool carriers and the work area door.
3. Flush work area with cooling lubricant.
4. Wipe clean with rags.
5. Apply an oil film to bare metal plates and telescopic covers.
6. Check plates for damage, repair or replace if necessary.

7.



When cleaning the drive area, make sure that the dirt does not penetrate directly into the path measuring systems and the ballscrews. The cleaning process must not aggravate the contamination of the components.

Clean drive area. Spray cooling lubricant onto the drive area around the supports of the guide bars and then sweep off the rough dirt down into the drag of the machine with a hand brush. Afterwards rub with rags.

8.



When cleaning the spindle carriers, make sure that the dirt does not penetrate directly into the spindle encoders. The cleaning process must not aggravate the contamination of the components. Follow the manufacturer's documentation.

Cleaning of the spindle carriers of the main and counter spindles. Remove machine covers in the area of the spindles. Then remove and clean the spindle covers.

9. Clean the machine base. Remove accumulations of chips, especially in the area of the counter spindle. For this purpose, move the counter spindle towards the main spindle and flush the area with cooling lubricant in the direction of the chip conveyor. Sweep the dirt arising from the cleaning of the drive area also in the direction of the chip conveyor and then flush with cooling lubricant. Afterwards rub with rags.

10. Clean and reinstall machine covers.


11. Clean the collecting tray under the workpiece handling unit.

**DL015** - Check shutters for function and auto stop

## Orientation

The shutter on the machine serves as access to the drive area. Check the opening and closing function of the shutter. The auto stop of the shutter must be ensured in all positions.


## Procedure



Example: Shutter on TNL20

Check the shutter function. It must be possible to fully open and close the shutter. The upper cover sheets can be removed for replacement/repair.

2.



**Example: Shutter holding spring on TNL20, view from the rear of the machine.**

- a** Fixing screw for shutter holding spring
- b** Shutter holding spring with hexagon head

Check the shutter for auto stop.

Readjust the tension of the holding spring if necessary until the shutter auto stop is ensured. To adjust the holding spring, fix the hexagon head (b) with a wrench, remove the fixing screw (a), turn the holding spring by 90° with the wrench, and secure the holding spring again by turning in the fixing screw. Check the shutter once more. Repeat the procedure, if necessary.

## DL020 - Check pressure accumulator (optional for TNL20.2)

### Orientation

A pressure accumulator consists of two chambers, a liquid and a gas section with a membrane as a separator. The liquid section is connected to the hydraulic circuit, so that the bubble reservoir is filled when the pressure rises, thereby compressing the gas. When the pressure drops, the compressed gas expands and displaces the stored pressurized liquid into the circulation. This ensures that the pressure level is maintained during load changes or temporary higher loads.



Screws on the hydraulic system, the connected components, and the supply lines must be tightened to the manufacturer's specified torques.

### Procedure

1. Check the pressure accumulator. With the machine powered on (not during the program or continuous run), slowly open the accumulator drain valve on the hydraulic fluid tank and watch the needle on the system pressure gauge.

The pressure gauge needle slowly falls to a point where it quickly drops to zero. This point is the approximate accumulator bias tension. This value is 50 +/-2 bar. **If this value is below 40 bar, the pressure accumulator must be replaced.**

## DL032 - Check coolant, sacrificial anode, and screen in separate cooling circuit

### Orientation


For add-on equipment that cannot be cooled conventionally with cooling lubricants or hydraulic fluid due to high temperature development, separate cooling is provided in an independent cooling circuit. The coolant used here should be checked continuously for its condition.



Due to different requirements and/or specifications of the respective manufacturers, be sure to review the respective manufacturer's documentation!



For all work in connection with operating fluids, the information in the data sheets of the respective manufacturers and the information in the document **Information on operating fluids** must be followed.



Example: Spindle cooling of main and counter spindle TNL20

a Cooling unit for main and counter spindle cooling

### Requirement



Top up only coolant of the same manufacturer having the same specification. Mixing different coolants may lead to corrosion of the cooling system and degradation of the coolant.

The machine is filled with a concentration of Antifrogen N (34% glycol) at the factory.






When switching the coolant to another product or changing the manufacturer, the cooling system must be completely flushed and cleaned with this coolant. Only then the machine may be put back into operation.

## Procedure

1. Check coolant. Test criteria for this visual inspection are the clarity and purity of the coolant.

If necessary, replace the coolant according to the manufacturer's requirements

2. Check fill level
3. Shut-off valves (b and c) must be closed for subsequent maintenance activities.
- 4.




Example: Liquid-air cooling system TNL32 compact

- a Sacrificial anode  
b, c Shut-off valves

Check sacrificial anode (a), replace if necessary.

5.



**Example: Liquid-water cooling system**

**d** Screen in supply line to cooling unit

Clean the screen in the supply line to the separate cooling unit, replace if necessary. To do so, open the blanking plug and remove the stainless steel screen.

6. Open the shut-off valves (b and c) again after maintenance activities have been completed.

## DL054 - Check central lubrication unit


## Orientation



Due to different requirements and/or specifications of the respective manufacturers, be sure to review the respective manufacturer's documentation!



Only oil of viscosity class ISO VG 220 must be used to lubricate the TNL20.2 and TNL32 compact.



Example: Central lubrication\_TNL32 compact

- 1 Central lubrication unit
- 2 Lubricating oil level indicator
- 3 Lubricating oil filler neck
- 4 System pressure display

### Lubrication points of central lubrication unit

- X/Y/Z axis lower/upper turret → guide cart, screw drive
- Tool drive in lower/upper turret → drip lubrication, gear
- Z axis main spindle → guide cart, screw drive
- X/Z axis counter spindle → guide, ball screw
- Workpiece removal unit to the left (option) → guide and gear rack
- X/Z axis front working unit → guide, ball screw (TNLxx-11)
- Front working unit tool drive → oil/air lubrication (TNLxx-11)



For all work in connection with operating fluids, the information in the data sheets of the respective manufacturers and the information in the document **Information on operating fluids** must be followed.



Screws on the lubrication system, the connected components, and the supply lines must be tightened to the manufacturer's specified torques.

## Requirement



Use only the original filters according to the spare or wear parts list.



Service and maintenance are to be carried out according to the manufacturer's specifications.

The maintenance of the central lubrication unit system requires the following auxiliary or working equipment:

- Use an ample supply of cleaning rags.
- A sufficient amount of lubricating oil for topping up/changing.
- Replacement filters for lubricating oil tank if necessary.

## Procedure

1. Check fill level of the central lubrication unit; top up if necessary.
2. Check lubrication pressure and related sensors.
3. Approx. 10 x apply lubrication pulse in the control.
4. Monitor the area around the lubricating oil distributor for leakage

**DL058** - Check pneumatic unit


## Orientation

The pneumatic unit is composed of the two System Part (1a-1h) and Linear Measuring System (1i-1n) components. To ensure trouble-free operation, periodic checks of the pneumatic unit are necessary.

- Check oil level at oiler (optional).
- Check system pressure and sealing air settings.
- Check fluid lines.
- Drain condensate (not applicable to auto-drain).
- Check pressure setting on the differential pressure monitoring gauge.



Due to different requirements and/or specifications of the respective manufacturers, be sure to review the respective manufacturer's documentation!



**Pneumatic system unit TNL32 compact**


- 1a** Manual switch-on valve
- 1b** Filter regulating valve / system pressure gauge 6 bar
- 1c** Filter insert 40 µm
- 1d** Filter insert 5 µm
- 1e** Branch module with system pressure sensor
- 1f** Electrical turn-off valve
- 1g** Branch module for functions
- 1h** Pressure regulating valve for sealing air
- 1i** Distribution block
- 1j** Filter insert 1 µm
- 1k** Filter insert 0.01 µm
- 1l** Activated carbon
- 1m** Pressure regulating valve/pressure sensor
- 1n** Differential pressure sensor for linear measuring system



Dirty filter cartridges must never be cleaned but always replaced. Filter cartridges are hazardous waste and must be disposed of according to local regulations.


Only filters with a filter fineness described in the fluid plans must be used.

## Procedure

1.  Power off the machine to depressurize the pneumatic unit and secure against accidental switching on.

Check oil level at oiler (optional).


2. Check the pressure setting on System Pressure and Sealing Air pressure gauges, and adjust if necessary. A system pressure of 6 bar and a sealing air pressure of 1 bar are set at the factory.
3. Check fluid lines (damage and leakage). Fluid lines must be checked for damage. Pre-damage such as kinks or abrasions should be logged and replacement should be initiated.



#### Replace activated carbon filter (by FESTO)

- X Filter base housing
- Y Filter bowl
- 1 Sealing ring
- 2 Activated carbon filter cartridge
- 3 O-ring


Check activated carbon filter; replace if necessary. **When disassembling the filter bowl, make sure that sealing rings and O-rings (1 + 3) are also installed.** Unscrew filter bowl (Y) from filter base (X) and remove activated carbon filter cartridge (2). Check sealing rings and O-rings (1 + 3); replace if necessary. Reinstall all parts in reverse order.



**Example: Exploded view of fine filter replacement (by FESTO)**


- 1 Filter bowl
- 2 Separating disk
- 3 Filter cartridge (check filter fineness)
- 4 Filter receptacle
- 5 O-ring

Check fine filter or microfilter, replace if necessary. **When removing the filter bowl, be sure to include the O-ring (5), separating disk (2), and filter receptacle (4).** Unscrew filter bowl (1) from filter base body and remove and check filter cartridge (3) ; replace if necessary. Check O-ring (5) ; replace if necessary. Reinstall all parts in reverse order.

6.  Condensate is extremely harmful to the environment due to its high pollution impact. Condensate must be collected in a container specifically marked for this purpose and properly disposed of.

Drain condensate (not applicable to auto-drain).

7. Switch on the machine.
8. Check the pressure setting on the system pressure gauge and adjust if necessary. A system pressure of 6 bar has been set at the factory.

9.  Dirty measuring systems or lack of sealing air can cause damage to the machine.

Check sealing air supply. To protect measuring systems or other components from the ingress of liquids or dirt, they are pressurized (1.0 bar). In this case, a low hiss is noticeable. To ensure trouble-free operation, periodic checks of the sealing air supply are necessary.



10. Check all fluid lines of the sealing air supply for damage.
11. Check the pressure setting on the sealing air pressure gauge and adjust if necessary. A pressure of 1 bar has been set at the factory.
12. Check sealing air supply on the components. A reliable method is the use of a suitable pressure gauge. The pressure gauge is attached to the line that is screwed off to monitor the existing pressure. The pressure should be in the range of the preset pressure of the sealing air supply. If this is not the case, the cause must be determined and the fault must be fixed.

**Alternatively, the following procedure can be used!**

Disconnect the fluid line in the area of the components and cover the opening of the fluid line with your finger. A slight counter pressure should be felt. Then connect the fluid line again.

13. Check the pressure settings on the differential pressure sensor for linear measuring system, adjust if necessary. An operating pressure of 1.0 bar has been set at the factory.

## DL075 - Check the cycloidal gear on the turret and on the front working unit




Carrying out the maintenance activities described below requires special knowledge. For this reason, these maintenance activities must only be carried out by staff that has received adequate training by the machine manufacturer!

### Orientation

The cycloidal gear must be checked on the turret and the front working unit by measuring the axial runout and the repeatability of the H axes and, where appropriate, of the B axis.

- H axis of front working attachment stations 1 to 6 → approx. 105 degrees
- H axis turret → 360 degrees
- B axis upper turret → approx. 100 degrees



Example: B axis and H axes TNL20

### Procedure

1. Check the cycloidal gear on the turrets by measuring the axial runout and the repeatability of the H axes, and of the B axis if necessary.
2. Check the cycloidal gear on the front working unit by measuring the axial runout and the repeatability of the H axis.

## DL111 - Check hydraulic system

## Orientation

To ensure trouble-free operation, periodic checks of the oil level are necessary. The fill level must be between the upper and lower marks on the oil sight glass.




Only use hydraulic fluid grade 15/13/10 in accordance with ISO 4406.

Viscosity other than 32 according to DIN ISO 3448 is not admissible.



For all work in connection with operating fluids, the information in the data sheets of the respective manufacturers and the information in the document **Information on operating fluids** must be followed.




**Example: Hydraulic unit TNL32 compact**

- 2a** System pressure display
- 2b** Hydraulic fluid filler neck
- 2c** Hydraulic fluid fill level indicator
- 2d** Hydraulic fluid filter/filter cartridge
- 2e** Electronic contamination indicator
- 2f** Accumulator drain valve
- 2g** Hydraulic fluid temperature display
- 2h** Metal filter
- 2i** Pressure accumulator
- 2j** Safety valve



Screws on the hydraulic system, the connected components, and the supply lines must be tightened to the manufacturer's specified torques.

## Procedure

1.  The hydraulic fluid level should always be near the top mark when the machine is switched off. During production, the oil level may drop after several consumers have been connected.

Check oil level at the oil sight glass.

2. Visual inspection of the hydraulic fluid. The hydraulic fluid may not exhibit any foaming or cloudiness at the oil sight glass. In case of problems of this kind, immediately determine the cause and correct the error. If in doubt, take a sample for analysis and contact the manufacturer of the hydraulic fluid.
3. Check pressure setting on pressure gauge and adjust if necessary. The value to be checked here is specified (see hydraulic diagram) and should be between 70-80 bar.
4. Check supply and fluid lines (damage and leakage). Supply and fluid lines must be checked for damage. Pre-damage such as kinks or abrasions should be logged and replacement should be initiated.

## DL160 - Determine axis ball screw backlash



Carrying out the maintenance activities described below requires special knowledge. For this reason, these maintenance activities must only be carried out by staff that has received adequate training by the machine manufacturer!

## Orientation



The Z axis should be adjusted around the machining position, as the backlash is not constant across the entire Z axis!


## Requirement

For backlash checking, the machine must have run warm for at least 3 h (traverse all axes).

For measuring the backlash, the machine must only be traversed by a CNC program, not with the handwheel.


## Procedure

1. Clamp a face-cut round part in the collet.
2. Attach dial gauge (accuracy 1/1000) to the tool carrier.



Move dial gauge into position


Move to the clamped turned part until the dial gauge probe is short of the hard stop (feed rate  $f = 200$  mm/min).



Back off the dial gauge by 1/2 measuring range


Back off the slide until the pointer of the dial gauge is within the indicating range ( $f = 150 \text{ mm/min}$ ).

5. Set the dial gauge pointer to "0".



Back off the dial gauge by 3 mm

Back off the slide by 3 mm (dial gauge is free) ( $f = 150 \text{ mm/min}$ ).



Advance the dial gauge by 3 mm

Advance the slide by 3 mm to the zero point ( $f = 150 \text{ mm/min}$ ).

8. Repeat the measurement five times and calculate the average.

Double this value and enter the result as backlash compensation into the control.

9. Remeasure for confirmation.

Should the backlash values for the X, Y and Z axes exceed 0.01 mm, they must be corrected by the machine manufacturer's service personnel.

**DL170 - Axes**

Carrying out the maintenance activities described below requires special knowledge. For this reason, these maintenance activities must be carried out only by authorized personnel of the manufacturer!

**Orientation**

Check the grid point spacing and the reference points of all axes, and correct if necessary.

**Requirement****Procedure**

1. Have the grid point spacing of all axes checked by the machine manufacturer's service personnel.
2. Have the reference points of all axes checked by the machine manufacturer's service personnel.

## DL175 - Check the system for reconditioning the cooling lubricant

### Orientation

Cooling and cleaning equipment for cooling lubricants is used where reconditioning of the cooling lubricant is necessary. Here, in order to achieve high availability of the cooling lubricant, the cooling lubricant is filtered (e.g., using edge gap filters, paper belt filters or vacuum rotation filters) and also cooled using coolers to a certain preset temperature.

Here, the filters, pressure and temperature sensors, valve functions and fluid lines of the devices must be checked.

Similarly, the supply lines to the machine and the fluid lines in the machine must be checked for damage such as abrasions or kinks or leakage.



For all work in connection with operating fluids, the information in the data sheets of the respective manufacturers and the information in the document **Information on operating fluids** must be followed.

### Requirement

To determine the concentration of cooling lubricant in the cooling lubricant, a measuring device (refractometer) is necessary.

### Procedure

1. Evaluate the overall impression of the system.
2. Visual inspection for leaks.

3.



Filters are hazardous waste and must be disposed of in a controlled manner.

Replace filter.

4. Check and potentially adjust float switch settings.
5. Check and potentially adjust temperature sensor settings.
6. Check and potentially adjust pressure sensor settings.



## DL180 - Check fire extinguishing system (visual inspection)

## Orientation




An examination of a fire extinguishing system may only be conducted directly by the manufacturer or a person with written authorization by the manufacturer.

Be sure to read the operating instructions of the manufacturer!

## Procedure

1.



Example: Kraft and Bauer stickers

Check sticker for manufacturing date.

2. Check sticker for inspection date.
3. Check sticker for battery replacement.

## DL225 - Replace toothed belts and check belt tension



Carrying out the maintenance activities described below requires special knowledge. For this reason, these maintenance activities must be carried out only by authorized personnel of the manufacturer!

### Orientation



Use only the original belts according to the spare or wear parts list.

Intact belts and correct belt tensions are necessary preconditions for trouble-free operation. Damaged belts must be replaced immediately.

**Frequency measurement of belt tension** Check the belt tensions with a frequency meter (e.g., from CLAVIS or Reiff). Place the frequency meter in the middle of the belt and lightly flick the belt (e.g., with the handle of a screwdriver) to set it in vibration. (If there are more than 2 pulleys, be sure to measure at the longest section of the belt).

### Requirement



After replacing a drive belt, be sure to observe the values (Hz) specified in the table below for the belt tension of the respective axis.  
**A frequency meter is required for testing.**

Also the reference point may need to be checked or adjusted.

### Procedure

1.



Caution

**Uncontrolled movements of axes or machine components.  
Severe cut and crush injuries.**

Secure all axes or components against uncontrolled movements during maintenance or repair work.

Move the tool slides to a suitable position.

2. Replace S5 belt.
3. Measure belt tension (frequency meter) and adjust belt.
4. Replace H1 belt.
5. Measure belt tension (frequency meter) and adjust belt.
6. Replace H2 belt.
7. Measure belt tension (frequency meter) and adjust belt.
8. Replace H3 belt.

9. Measure belt tension (frequency meter) and adjust belt.

## DL454 - Replacing hydraulic fluid

### Orientation



Power off the machine and secure it against power on.



Use only approved hydraulic fluid. Details can be found in the documentation and on the label of the hydraulic fluid tank.

When changing the type of hydraulic fluid, the unit must be flushed with new fluid.



For all work in connection with operating fluids, the information in the data sheets of the respective manufacturers and the information in the document **Information on operating fluids** must be followed.

### Requirement



Specification and quantity of hydraulic fluid as specified in the technical data.

Before replacing the hydraulic fluid, make sure that the required spare parts such as seals and filters are available.



Use only the original filters according to the spare or wear parts list.



Filters are hazardous waste and must be disposed of in a controlled manner.



Power off the machine, depressurize the hydraulic system by opening the accumulator relief valve(s), and protect against accidental power on.


### Procedure

1. Suction off old fluid through the filler neck **(2b)** or drain the fluid from the drain plug **(2k)**. Use a suitable collection bin for this purpose.

2.



Use only lint-free cleaning cloths or a sponge!




**Example: Hydraulic unit TNL32 compact**


- 2a** System pressure display
- 2b** Hydraulic fluid filler neck
- 2c** Hydraulic fluid fill level indicator
- 2d** Hydraulic fluid filter/filter cartridge
- 2e** Electronic contamination indicator
- 2f** Accumulator drain valve
- 2k** Oil drain plug

Replace filter.

3. Unscrew the filter bell (**Y**).

4.  Dispose of the fluid in the filter bell (**Y**) ; do **not** return it to the hydraulic tank.

Replace filters (**Z**) of the hydraulic fluid filters (**X**). A different number of hydraulic filters (**X**) may be installed, depending on the version. Unscrew filter bell (**Y**) , remove contaminated hydraulic fluid (oil sump) and used filter (**Z**) from the filter bell (**Y**) and dispose of them according to environmental regulations.

5.  Only filters with retained particle sizes described in the fluid plans must be used.



**Z**

**Example: Filter (Z)**

Clean filter bell **(Y)** and insert a new filter **(Z)**. Reinstall the filter bell **(Y)** and **tighten by hand until it stops**. Then back off the filter bell **(Y)** 1/8 turn.

6. To fill in new hydraulic fluid, use a pump with a min. 10 µm micro filter that is exclusively used for hydraulic fluid.
7. Fill in the prescribed amount of new hydraulic fluid.
8. Switch on the machine and hydraulic system.
9. Check and, if necessary, replenish hydraulic fluid level.
10. Vent hydraulic system. To bleed the hydraulic system, open the accumulator drain valve **(2f)** for about 10 seconds, and then close it again.

## DL480 - Check wipers on the guide carts of the workpiece removal unit and replace them, if necessary



Carrying out the maintenance activities described below requires special knowledge. For this reason, these maintenance activities must only be carried out by staff that has received adequate training by the machine manufacturer!

### Orientation

The wipers on the guide carts of the workpiece removal unit prevent the ingress of dirt into the ball screw. The outer wipers of the guide carts are easily accessible and thus can be replaced quickly. The entire guide cart under the workpiece removal unit can also be pushed out to replace the two wipers.

### Procedure

1. Move the workpiece removal unit to an appropriate position.
2. Check external wipers, replace if necessary. Loosen screws of wipers accessible from the outside and remove the wipers. Replace wipers.

#### **Alternatively, the following procedure can be used!**

Replace external and internal wipers. Loosen and remove screws of the accessible guide cart. Always remove one guide cart and replace one wiper after the other.

3.



Do not push guide cart from the guide bar. Balls of the linear ball bearing may be lost.

Carefully push out the guide cart from under the workpiece removal unit.

4.



New wipers must rest against the contour of the guide bar.

Replace inner and outer wipers.

5. Push the guide cart back under the workpiece removal unit and tighten the screws.

## DL486 - Replace wipers

### Orientation



Regular inspection of the wipers prevents damage to the wipers themselves and to the work area door.

If the work area door can be opened and/or closed only with increased effort, it can be expected that the wipers are already destroyed by accumulation of chips and swarf compaction.

### Requirement



Example: Chip hook and chip brush

Use appropriate tools to remove coarse chips, chip nests and other debris.

### Procedure



Example: 1 Removing chip nest using appropriate tools (e.g., chip hooks)



Remove large chips on the inside of the work area door from top to bottom. Use a chip hook for this purpose.


2.



Example: 2 Sweep small chips and other debris from top to bottom using chip brooms or brushes.

Remove small chips and chip accumulations on the inside of the work area door from top to bottom. Use a chip brush for this purpose.

3. Clean the area behind the wipers.



Example: Wipers work area TNL20

Replace wipers.

5.



Make sure that the wipers evenly contact the work area door before tightening the screws.

Check the wipers for proper seating. After the wipers have been replaced, the work area door should open and close again without much effort as usual

6.



If replacement of the wipers has not resulted in tangible improvement, the soiled rollers and the guide rail of the work area door must also be cleaned.

Clean rollers and guide rail of the work area door.

## DL491 - Clean drain holes at the Z cover of the upper tool carrier

### Orientation




The drain holes at the Z cover of the upper tool carrier should be cleaned at regular intervals, so that any cooling lubricant behind can drain into the work area.

### Requirement

Use appropriate tools to remove coarse chips, chip nests and other debris.

### Procedure



Example: Drain hole of work area TNL20

Remove cover sheets over the drain holes and clean the drain holes with a brush, for example.

2. Reattach the cover sheets over the drain holes.


## DL494 - Replace wipers and, if necessary, O-ring(s) on sleeve for fixed headstock operation (main spindle).



Carrying out the maintenance activities described below requires special knowledge. For this reason, these maintenance activities must be carried out only by authorized personnel of the manufacturer!

### Orientation

For fixed headstock operation, mount a sleeve with wiper and, if necessary, O-ring(s) on the main spindle. This seals the spindle area (main spindle/guide sleeve) between the work area and the drive area during fixed headstock operation.



**Example: Sleeve with wiper and O-ring on TNL32 compact**

- a** Guide sleeve
- b** Wiper
- c** O-rings

### Requirement

A mounting device must be used when installing the new wiper, which can be requested from INDEX Service. Replace the wiper and the O-rings with the sleeve removed. If necessary, remove sleeve; for removal/installation, see document "Operation of the machine with bar stock, UNIMAG5 interface", chapter "Changeover from fixed to sliding headstock operation / Changeover sliding to fixed headstock operation". Grease the wiper and, if necessary, the O-ring(s) with suitable lubricant immediately before installing the sleeve. See the document "Information on working media."

## Procedure

1. Replace wiper and O-ring(s) if necessary.

## DL510 - Perform data backup

## Orientation

Using a current data backup, the machine can be restored to the original state before the failure after a defect of the internal storage device/NC control.

The file name of the data backup includes the machine type, machine number, and date/time of the backup.




Network settings and the customer's NC programs are not included in the backup.

Backup additionally to an external data carrier for access in case of a defect of the internal storage medium.

## Procedure

1. Connect USB device to USB port

- 2.



Example shown

Open **IN/OUT** screen and use **TAB** to activate the right part of the screen

3. Press **Softkey** Select (F3) (select appropriate target, e.g., USB)
4. Press **Softkey** Menu (F8) twice. Softkey text "Menu 3-3" appears
- 5.



Note that the backup includes no customer NC programs! Include them in a separate backup, if necessary

Press **Softkey** Backup (F1) and press **Softkey** OK (F1) to acknowledge the informational message

All relevant parameters and data for the backup are compiled

6. Press **Softkey** OK (F1) to confirm the transfer of the data to the desired storage location

## DL520 - Check control cabinet and cable assemblies (visual inspection)



Carrying out the maintenance activities described below requires special knowledge. For this reason, these maintenance activities must only be carried out by staff that has received adequate training by the machine manufacturer!

### Orientation

To avoid problems and prevent any resulting system failures, simplified control cabinet checks must be carried out at regular intervals on the cabinet and associated components. This include a visual inspection of the wire harnesses of the individual modules and the grounding cable. Additional built-in air conditioning units (option) ensure a constant temperature in the control cabinet. These air conditioners cannot work efficiently if filters are dirty or doors are not tight.



Use only the original filters according to the spare or wear parts list!

Filters are hazardous waste and must be disposed of in accordance with environmental guidelines and regulations of the country of operation.

When working in or on the control cabinet, switch off the machine and secure it against power on.

### Requirement



Even with the machine powered off, some devices or components in the control cabinet are still energized.



Observe the specific electrical diagrams for this machine.

### Procedure

1. Switch off the machine.
2. Have the electrical diagrams for the corresponding machine ready.
3. Replace all filters on the control cabinet and cabinet components.
4. Check that the cabinet doors can be properly closed. If the cabinet doors can not be closed properly, determine the cause and eliminate it. Possible causes could be faulty seals, hinges, or even a damaged cabinet door.
5. Check all cabinet seals. They should be free of oil and condensation.
6. Clean the control cabinet. Use a suitable vacuum cleaner for this purpose.
7. Check the cabinet lighting (optional).



8. Check grounding cable. Grounding cables are located, e.g., between the control cabinet and cabinet doors and between the base and the machine bed.
9. Check all connections in the control cabinet, tighten loose connections

10.

**Danger from electricity**

The charge lamp should be off (must not illuminate).  
Measure the voltage at the power rails to ensure they are de-energized.

Remove the covers from the power rails of the amplifiers and retighten all connections. Then reinstall the covers.

11. Check cable assemblies for damage, replace if necessary.

## DL525 - Check the fan and fan cover in the control cabinet, clean if necessary



Carrying out the maintenance activities described below requires special knowledge. For this reason, these maintenance activities must only be carried out by staff that has received adequate training by the machine manufacturer!

### Procedure

1.



Caution

**Electrical equipment or parts thereof are under dangerous voltage.**

**Electric shock.**

Switch off the machine and lock it out.



Example: Fan in control cabinet, TNL20

Check the fan and fan cover in the control cabinet for dirt, clean if necessary.

**DL590** - Check inspection/replacement date of the backup battery/batteries in the control cabinet (NC)

Carrying out the maintenance activities described below requires special knowledge. For this reason, these maintenance activities must only be carried out by staff that has received adequate training by the machine manufacturer!

**Orientation**

To ensure that no important machine data is lost in the event of a power failure, backup batteries or rechargeable batteries are installed at various points of the machine, which must be regularly tested and/or replaced. The backup batteries described here have a lifespan of 4 years after which they must be replaced promptly.



Due to different requirements and/or specifications of the respective manufacturers, be sure to review the respective manufacturer's documentation!

**Requirement**


Prior to this maintenance activity, make sure that you have a sufficient number of batteries or rechargeable batteries available.

The required number of backup batteries varies depending on the configuration level of the machine. The number of required backup batteries can be found in the electrical diagrams of the machine or obtained from the customer service of the machine manufacturer.

**Procedure**

1. Switch off drives.
2. Press the EMERGENCY STOP button.

3.



NC backup battery in the control cabinet

Open the battery compartment cover.

4. Remove the battery including connectors.
5. Insert a new battery and plug in the connectors.

6.



Example of the data to be logged in a maintenance schedule.

- approved/replaced on:
- Name:
- Signature:

Record testing or replacement date in a maintenance schedule.

7. Record testing or replacement date of NC backup battery in the control cabinet.
8. Close covers.

**DL636** - Check the replacement interval of the servo backup batteries at the axis servos.

Carrying out the maintenance activities described below requires special knowledge. For this reason, these maintenance activities must only be carried out by staff that has received adequate training by the machine manufacturer!

**Orientation**

To ensure that no important machine data is lost in the event of a power failure, backup batteries or rechargeable batteries are installed at various points of the machine, which must be regularly tested and/or replaced. The axis servo backup batteries described here have a lifespan of 4 years after which they must be replaced promptly.



Due to different requirements and/or specifications of the respective manufacturers, be sure to review the respective manufacturer's documentation!

**Requirement**


Prior to this maintenance activity, make sure that you have a sufficient number of batteries or rechargeable batteries available.

The number of axis servos and thus the required number of backup batteries vary depending on the configuration of the machine. The number of required backup batteries can be found in the electrical diagrams of the machine or obtained from the customer service of the machine manufacturer.

**Procedure**

1. Switch on the NC.
2. Press the EMERGENCY STOP button.

3.



Servo backup battery in control cabinet

Disconnect and remove the servo backup battery.

4. Connect a new servo backup battery and insert it into the axis servo.

5.



Example of the data to be logged in a maintenance schedule.

- Axis servo:
- approved/replaced on:
- Name:
- Signature:

Record testing or replacement date in a maintenance schedule.

## **Service Interval - 8.000 Operating hours**

## Maintenance Summary - 8.000 Operating hours



It is recommended to document the maintenance activities carried out by using the appropriate maintenance log. The maintenance log has the document number DTE098EN - 15.08.2024.

- EL016** - Check the seals on the rotary distributor of the turret and the front working attachment; replace if necessary
- EL030** - Check automatic work area door with Xcenter (option)
- EL040** - Replace telescopic plates
- EL042** - Replace profile wiper on main spindle



**EL016** - Check the seals on the rotary distributor of the turret and the front working attachment; replace if necessary



Carrying out the maintenance activities described below requires special knowledge. For this reason, these maintenance activities must be carried out only by authorized personnel of the manufacturer!

## Orientation

Check the Glydring seals of the rotary distributor on the turrets and on the front working unit for leakage. Also check the O-ring gaskets on the cooling lubricant transfer kidney/pin on the turrets for leakage.


## Procedure

1. Check the Glydring seals of the rotary distributor on the turrets and on the front working unit, replace if necessary.
2. Check the O-ring gaskets on the cooling lubricant transfer kidney/pin on the turrets for leakage, replace if necessary.

## EL030 - Check automatic work area door with Xcenter (option)

### Orientation

When using the optional automatic work area door in conjunction with Xcenter, the two guide carts of the linear guideway must be lubricated in accordance with the manufacturer's specifications. Also, the casters must be checked, and replaced if necessary.



Example: TNL20, automatic work area door, iXcenter




Example: TNL20, automatic work area door, casters

### Procedure


1.



Follow the corresponding manufacturer's documentation.




Example: TNL20, automatic work area door, iXcenter



Example: TNL20, automatic work area door, iXcenter

On automatic work area door in conjunction with Xcenter, lubricate the two guide carts of the linear guideway in accordance with the manufacturer's specifications.



**TNL20 Aut. work area door casters**

On automatic work area door in conjunction with Xcenter, check the rollers, and replace with new rollers if necessary.

## EL040 - Replace telescopic plates

### Orientation

The telescopic plates in the work area must be replaced at regular intervals in order to ensure their function.

### Requirement




**Example: Chip hook and chip brush**

Use appropriate tools to remove coarse chips, chip nests and other debris.

## Procedure

1.



Example: Section Work area door\_TNL32 compact

Replace telescopic plates in work area.


**EL042** - Replace profile wiper on main spindle**Orientation**

The profile wiper on the main spindle in the work area must be replaced at regular intervals in order to ensure its function.

**Requirement**

Example: Chip hook and chip brush

Use appropriate tools to remove coarse chips, chip nests and other debris.

**Procedure**

Example: Profile wiper on main spindle, TNL32 compact

Replace profile wiper on main spindle in the work area.





## **Service Interval - 5 Years**

## Maintenance Summary - 5 Years



It is recommended to document the maintenance activities carried out by using the appropriate maintenance log. The maintenance log has the document number DTE098EN - 15.08.2024.

- IL010** - Replacing the pneumatically pilot- controlled cooling lubricant valves
- IL020** - Replace pressure accumulator (optional for TNL20.2)
- IL060** - Check the pretension on the spindle bearings on the main and counter spindles

**IL010** - Replacing the pneumatically pilot- controlled cooling lubricant valves

## Orientation

In the course of the machine's operating time, internal wear of the pneumatically pilot-controlled cooling lubricant valves may occur, with the result that cooling lubricant may penetrate the pneumatic control lines. To avoid consequential damage, **INDEX** recommends replacing these valves after 5 years.

## Requirement



Due to different requirements and/or specifications of the respective manufacturers, be sure to review the respective manufacturer's documentation!



Power off the machine to depressurize the pneumatic system and secure against accidental switching on.

## Procedure

1. Renew valves.

## IL020 - Replace pressure accumulator (optional for TNL20.2)

### Orientation



According to the pressure equipment directive 97/23/EC, the pressure accumulators built into the machine are of category I/ module A. They are provided with a CE mark by the manufacturer, and a declaration of conformity has been issued. Due to this categorization, the pressure accumulators must be subjected to an external and internal inspection and a strength test by a qualified person after a period of time recommended by the pressure accumulator's manufacturer. For pressure units with gas cushions, an internal inspection is recommended after 10 years at the latest. We recommend to replace the pressure accumulator after 5 years to avoid an internal inspection that is laborious and expensive for this size of pressure accumulator.



Due to different requirements and/or specifications of the respective manufacturers, be sure to review the respective manufacturer's documentation!



The machine owner/operator is obliged to check the pressure accumulator according to applicable rules and directives. Defective pressure accumulators must be disposed of according to applicable rules after they have been depressurized by a qualified technician. The guidelines and regulations applicable in the country of use must be followed.



Screws on the hydraulic system, the connected components, and the supply lines must be tightened to the manufacturer's specified torques.

### Procedure

1. Replace the pressure accumulator.

2.



**Example: Pressure accumulator**

Connect and secure the pressure accumulator. Observe the tightening torque.

**IL060** - Check the pretension on the spindle bearings on the main and counter spindles

Carrying out the maintenance activities described below requires special knowledge. For this reason, these maintenance activities must be carried out only by authorized personnel of the manufacturer!

**Procedure**

1. Check the pretension on the spindle bearing of the main spindle.
2. Check the pretension on the spindle bearing of the counter spindle.

## **Service Interval - 8 Years**

## Maintenance Summary - 8 Years



It is recommended to document the maintenance activities carried out by using the appropriate maintenance log. The maintenance log has the document number DTE098EN - 15.08.2024.

**JL005** - Note on replacing the window pane or removing the design pane

**JL010** - Replace the window pane



## JL005 - Note on replacing the window pane or removing the design pane



Carrying out the maintenance activities described below requires special knowledge. For this reason, these maintenance activities must only be carried out by staff that has received adequate training by the machine manufacturer!

### Orientation



The instructions described in this point only serve as information for the subsequent maintenance activity **“replace window pane”** of the respective machines.




If the window pane is damaged, it must be replaced. This is necessary regardless of the extent of damage. Even with minimal damage, the impact resistance of the pane can no longer be guaranteed.



For safety reasons, it is recommended to obtain the window pane directly from the machine manufacturer or its country representative.

The window pane consists of three panes. the inner pane of tempered glass, the central pane of polycarbonate, and the outer pane also made of polycarbonate. The inner pane is relatively resistant. It can be cleaned with any commercially available cleaning agents. Only the center pane is essential for the impact resistance of the window pane. The polycarbonate panes are subject to natural aging and must be replaced at regular intervals.



Example: TNA400.2 Work area door

- a** Outer pane (design pane made of PMMA – polymethyl methacrylate)
- m** Center pane (polycarbonate)
- i** Inner pane (glass)
- s** Silicone gasket


Depending on the machine type, it may be necessary to remove a handle attached here before dismantling the design disks.

Requirement



General information. **The values indicated in the table must be strictly observed.**

			C	
A		B	X	Y
TNL20 TNL20.2 TNL32 compact	–	46	617	110,5
TNA400.2/3 TNA500.2/3	+	67	603	48
TNA500.3* <sup>1)</sup>	+	81	603	48
TNX220.3	+	91,5	707	166



Example: Design pane specifications for the respective machines

- A Machine designation
- B Weight (kg)
- C Values for centers of gravity
- Y Y-value (mm)
- X X-value (mm)
- \*1 Turning length 1200 mm



From a weight of approx. 80kg, the use of lifting equipment (cranes, forklifts or similar) is recommended. The machines marked with + in the table ( **example: design pane specifications...** ) have threaded bushings at the top of the design pane and are therefore crane-compatible.

If the design pane is not removed using a crane or other lifting equipment but by hand using suction lifters, it is imperative that the current Load Handling Ordinance (**LasthandhabV** ) be taken into account. When using suction lifters (see example), be sure to select the appropriate size or type according to the table ( **example: design pane specifications...** ).



The locally valid guide lines and regulations must be taken into consideration.



Example: Bohle suction lifter 60 kg-100 kg

## Procedure

1. If you have questions, be sure to contact the **INDEX** service department or an **INDEX** representative.

## JL010 - Replace the window pane



Carrying out the maintenance activities described below requires special knowledge. For this reason, these maintenance activities must only be carried out by staff that has received adequate training by the machine manufacturer!

### Orientation



If the window pane is damaged, it must be replaced. This is necessary regardless of the extent of damage. Even with minimal damage, the impact resistance of the pane can no longer be guaranteed.



For safety reasons, it is recommended to obtain the window pane directly from the machine manufacturer or its country representative.



Example: Design element TNL20

The design element consists of the work area door with a permanently-attached design pane. The design element covers the window pane on the operator's side. The window pane consists of three panes: the inner pane of tempered glass, the central pane of polycarbonate, and the outer pane also made of polycarbonate. The inner pane is relatively resistant. It can be cleaned with any commercially available cleaning agents. Only the center pane is essential for the impact resistance of the window pane. The polycarbonate panes are subject to natural aging and must be replaced at regular intervals.


There is a safety label on the window pane indicating the part no., year of manufacture, and manufacturer. The first replacement of the window pane is due 8 years after production of the machine (see type plate).

Make sure of the correct mounting position (safety glass facing the work area) when replacing the polycarbonate safety glass. The safety label should be readable from the outside.



**Cleaning the window pane.** The inside of the window pane is scratch-resistant. Any commercial cleaning agent can be used here.  
**Cleaning the cover pane.** The cover pane is sensitive to scratches on the operator side! Clean the cover pane with a soft cloth or sponge and glass cleaner or soap and water. Use no abrasive or alkaline cleaning agents and no sharp-edged items.

## Procedure



**Example: Window pane TNL20**

- a** Design pane on operator side
- b** Window pane on work area side

Replace the window pane.

# INDEX

**INDEX-Werke GmbH & Co. KG**  
**Hahn & Tessky**

Plochinger Str. 92  
D-73730 Esslingen, Germany

Fon +49 711 3191-0  
Fax +49 711 3191-587

[info@index-werke.de](mailto:info@index-werke.de)  
[www.index-werke.de](http://www.index-werke.de)